SHOP MANUAL

KOMATSU


D85C

PIPE LAYER

KOMATSU® LTD.

MidWestTech | Komatsu D85C Pipe Layer Service Manual | Publication S85C.12-BE1 Order the manual at mid-west-tech.com >

WINCH ASS'Y



1	Case	67	Spacer	133	Spring washer
2	Bearing	68	Bolt	134	Dowel
3	Shaft	69	Spring washer	135	Cace cover
4	Nut	70	Frange	136	Bearing
5	Pin	71	Screw	137	Bearing
6	Lock	72	Nipple	138	Bolt
7	Lock	73	Cage	139	Spring washer
8	Bolt	74	O-ring	140	Seal
9	Plate	75	O-ring	141	Cover
10	Bolt	76	Bolt	142	O-ring
11	Spring washer	77	Spring washer	143	Bolt
12	Spacer	78	Bearing	144	Spring washer
13	Gear	79	Cage	145	Holder
14	Bushing	80	O-ring	146	Shim
15	Collar	81	Bolt	147	Shim
16	Inner race	82	Spring washer	148	Lock
17	Gear	83	Seal	149	Bolt
18	Gear	84	Frange	150	Cover
19	Gear	85	Spacer	151	O-ring
20	Bushing	86	Bolt	152	Bolt
21	Collar	87	Spring washer	153	Spring washer
22	Gear	88	Frange	154	Bracket
23	Spacer	89	Screw	155	O-ring
24	Gear	90	Nipple	156	Bolt
25	Bushing	91	Tube	157	Spring washer
26	Collar	92	O-ring	158	Washer
27	Inner race	93	O-ring	159	Seal
28	Gear	94	Bolt	160	Drum
29	Gear	95	Spring washer	161	O-ring
30	Spacer	96	Gear	162	Lock
31	Shaft	97	Gear	163	Bolt
32	Bearing	98	Gear	164	Tube
33	Plate	99	Spacer	165	Bolt
34	Bolt	100	Washer	166	Spring washer
35	Spring washer	101	Nut	167	O-ring
36	Gear	102	Shaft	168	Spring pin
37	Gear	103	Bracket	169	O-ring
38	Cage	104	Bushing	170	Valve
39	Bearing	105	Fitting	171	Plug
40	O-ring	106	Ball	172	O-ring
41	Bolt	107	Bracket	173	Tube
42	Spring washer	108	Washer	174	O-ring
43	Seal	109	Nut	175	Bolt
44	Plate	110	Seal	176	Spring washer
45	Bolt	111	Cage	177	Gauge
46	Spring washer	112	Bearing	178	Breather
47	Sheft	113	Holder	179	Plug
48	Collar	114	O-ring	180	O-ring
49	Drum	115	Bolt	181	Bolt
50	Bearing	116	Spring washer	182	Plug
51	Ring	117	O-ring	183	Name plate
52	Key	118	Elbow	184	Screw
53	Collar	119	Cover	185	Rope
54	Oil seal	120	Seal	186	Rope
55	Drum	121	Cage	187	Wedge
56	Bearing	122	Bearing	188	Rotary joint
57	Ring	123	Ring	189	O-ring
58	Oil seal	124	O-ring	190	Plate
59	Collar	125	Ring	191	Bolt
60	Bearing	126	Seal	192	Spring washer
61	Cage	127	Bolt	193	Clip
62	O-ring	128	Spring washer	194	Nut
63	Bolt	129	Seal	195	Washer
64	Spring washer	130	Cover	196	Dowel pin
65	Seal	131	O-ring	197	Bolt
66	Frange	132	Bolt	198	Spring washer

MidWestTech | Komatsu D85C Pipe Layer Service Manual | Publication S85C.12-BE1

Order the manual at mid-west-tech.com >