MidWestTech | Komatsu D57S-1 Dozer Shovel Operation & Maintenance Manual | Publicat...

SEAM0135B101

Operation & Maintenance Manual

KOMATSU®

D57S-1

DOZER SHOVEL

SERIAL NUMBER
D57S- 20001 and up

Order the manual at mid-west-tech.com >

CONTENTS

OPERATION

GENERAL LOCATIONS AND SPECIFICATIONS 4
INSTRUMENTS AND CONTROLS 5
CHECK BEFORE STARTING 17
OPERATING YOUR MACHINE 22
COLD WEATHER OPERATION 34
HOW TO USE INCHING PEDAL 39
ADJUSTMENT OF WORK EQUIPMENT 43
REPLACEMENT OF BUCKET TEETH 45
TIPS FOR LONGER UNDERCARRIAGE LIFE 46

MAINTENANCE

PERIODIC MAINTENANCE 47
PERIODICAL REPLACEMENT OF SAFETY PARTS 48
MAINTENANCE TABLE 50
EVERY 50 HOURS SERVICE 53
EVERY 250 HOURS SERVICE 54
EVERY 500 HOURS SERVICE 61
EVERY 1000 HOURS SERVICE 64
EVERY 2000 HOURS SERVICE 70
EVERY 4000 HOURS SERVICE 78
WHEN REQUIRED 79
ADJUSTMENT 87
TROUBLE SHOOTING GUIDE 91
SERVICE METER 94
MACHINE AND ENGINE SERIAL NUMBERS 95
FUEL, COOLANT AND LUBRICANTS 96

MidWestTech | Komatsu D57S-1 Dozer Shovel Operation & Maintenance Manual | P... Order the manual at mid-west-tech.com >