MidWestTech | Komatsu D65A-8, D65E-8, D65P-8 Bulldozer Operation & Maintenance Man...

Operation & Maintenance Manual

SEAM01440805

D65A,E,P-8

BULLDOZER

SERIAL NUMBERS D65A,E,P-45001 and up

KOMATSU®

Order the manual at mid-west-tech.com >

CONTENTS

OPERATION

GENERAL LOCATIONS AND SPECIFICATIONS .. 5
OPERATOR'S COMPARTMENT 6
INSTRUMENTS AND CONTROLS 8
CHECK BEFORE STARTING 18
OPERATING YOUR MACHINE 24
COLD WEATHER OPERATION 36
BULLDOZER'S WORK 41
BLADE OPERATION 43
BLADE ADJUSTMENT 46
REVERSING OF CUTTING EDGE
AND REPLACEMENT OF END BIT 49
TIPS FOR LONGER UNDERCARRIAGE LIFE 50
TRANSPORTATION 51

MAINTENANCE

PERIODIC MAINTENANCE 53
MAINTENANCE TABLE 54
EVERY 250 HOURS SERVICE 57
EVERY 500 HOURS SERVICE 66
EVERY 1000 HOURS SERVICE 69
EVERY 2000 HOURS SERVICE 75
EVERY 4000 HOURS SERVICE 76
WHEN REQUIRED 77
ADJUSTMENT 87
TROUBLE SHOOTING GUIDE 91
STORAGE 94
SERVICE METER 96
MACHINE AND ENGINE SERIAL NUMBERS 97
FUEL, COOLANT AND LUBRICANTS 98

ENGINE EQUIPPED WITH TURBOCHARGER 101

MidWestTech | Komatsu D65A-8, D65E-8, D65P-8 Bulldozer Operation & Maintenance... Order the manual at mid-west-tech.com >