Operation & Maintenance Manual

SEAM02010602

[redacted]

PC60-6
PC60L-6
PC90-1

HYDRAULIC EXCAVATOR

SERIAL NUMBERS PC60-28001
PC60L-8001 and up
PC90-1001

WARNING

Unsafe use of this machine may cause serious injury or death. Operators and maintenance personnel must read this manual before operating or maintaining this machine. This manual should be kept near the machine for reference and periodically reviewed by all personnel who will come into contact with it.

NOTICE

Komatsu has Operation & Maintenance Manuals written in some other languages. If a foreign language manual is necessary, contact your local distributor for availability.

KOMATSU®

MidWestTech | Komatsu PC60-6, PC60L-6, PC90-1 Hydraulic Excavator Operation & Mainte... Order the manual at mid-west-tech.com >

CONTENTS

OPERATION

GENERAL LOCATIONS AND SPECIFICATIONS 4
INSTRUMENTS AND CONTROLS 6
HANDLING POWER MODE SWITCH 40
CHECK BEFORE STARTING 44
OPERATING YOUR MACHINE 50
CHANGING SWING RADIUS (For PC60, PC60L) 72
INVERSION AND REPLACEMENT OF BUCKET 74
SELECTION OF TRACK SHOES 76
INSTALLATION OF OPTIONAL ELECTRICAL EQUIPMENT 78
COLD WEATHER OPERATION 82

MAINTENANCE

PERIODIC MAINTENANCE 91
- BLEEDING AIR FROM CIRCUIT 92
- PERIODICAL REPLACEMENT OF SAFETY PARTS 96
- MAINTENANCE TABLE 100
- OIL FILLER AND LEVEL GAUGE POSITIONS 104
- EVERY 50 HOURS SERVICE 106
- EVERY 100 HOURS SERVICE 106
- EVERY 250 HOURS SERVICE 112
- EVERY 500 HOURS SERVICE 116
- EVERY 1000 HOURS SERVICE 122
- EVERY 2000 HOURS SERVICE 124
- WHEN REQUIRED 128

ADJUSTMENT 148
TROUBLE SHOOTING GUIDE 150
SERVICE METER 158
MACHINE AND ENGINE SERIAL NUMBERS 160
FUEL, COOLANT AND LUBRICANTS 162

MidWestTech | Komatsu PC60-6, PC6... Order the manual at mid-west-tech.com >

GENERAL LOCATIONS AND SPECIFICATIONS

1. Bucket
2. Bucket cylinder
3. Arm
4. Arm cylinder
5. Boom
6. Boom cylinder
7. Sprocket
8. Track frame
9. Idler
10. Track shoe

MACHINE MODEL			PC60	PC60L	PC90
PERFORMANCE	Bucket capacity (m^3)	[SAE]	0.28	0.28	0.40
		[CECE]	0.25	0.25	0.35
	Travel speed (km/h)	Hi	5.0	4.6	5.0
		Lo	3.7	3.2	3.3
	Swing speed (rpm)		14.5	14.5	13.5
OPERATING WEIGHT (kg)			6580	6980	8380
ENGINE	Model		Komatsu 4D95L Diesel Engine		
	Flywheel horsepower (HP) [Rated rpm]		54.2 [2100]	54.2 [2100]	64.1 [2300]

NOTE: Specifications are subject to change without notice.

MidWestTech | Komatsu PC60-6, PC6... Order the manual at mid-west-tech.com >