SEAM02010604

Operation & Maintenance Manual

PC60-6
PC60L-6
PC90-1

HYDRAULIC EXCAVATOR

SERIAL NUMBERS
PC60 -34101
PC60L- 8076 and up
PC90 - 1404

WARNING

Unsafe use of this machine may cause serious injury or death. Operators and maintenance personnel must read this manual before operating or maintaining this machine. This manual should be kept near the machine for reference and periodically reviewed by all personnel who will come into contact with it.

NOTICE

Komatsu has Operation & Maintenance Manuals written in some other languages. If a foreign language manual is necessary, contact your local distributor for availability.

KOMATSU®

MidWestTech | Komatsu PC60-6, PC60L-6, PC90-1 Hydraulic Excavator Operation & Mainte... Order the manual at mid-west-tech.com >

CONTENTS

OPERATION

GENERAL LOCATIONS AND SPECIFICATIONS 4
INSTRUMENTS AND CONTROLS 6
HANDLING POWER MODE SWITCH 40
CHECK BEFORE STARTING 44
OPERATING YOUR MACHINE 50
CHANGING SWING RADIUS (For PC60, PC60L) 76
INVERSION AND REPLACEMENT OF BUCKET 78
SELECTION OF TRACK SHOES 80
INSTALLATION OF OPTIONAL ELECTRICAL EQUIPMENT 82
COLD WEATHER OPERATION 86

MAINTENANCE

PERIODIC MAINTENANCE 95
BLEEDING AIR FROM CIRCUIT 96
PERIODICAL REPLACEMENT OF SAFETY PARTS 100
MAINTENANCE TABLE 104
OIL FILLER AND LEVEL GAUGE POSITIONS 108
EVERY 50 HOURS SERVICE 110
EVERY 100 HOURS SERVICE 110
EVERY 250 HOURS SERVICE 116
EVERY 500 HOURS SERVICE 120
EVERY 1000 HOURS SERVICE 126
EVERY 2000 HOURS SERVICE 128
WHEN REQUIRED 132
ADJUSTMENT 152
TROUBLE SHOOTING GUIDE 154
SERVICE METER 162
MACHINE AND ENGINE SERIAL NUMBERS 164
FUEL, COOLANT AND LUBRICANTS 166
MACHINES READY FOR ATTACHMENTS 169

MidWestTech | Komatsu PC60-6, PC6... Order the manual at mid-west-tech.com >

GENERAL LOCATIONS AND SPECIFICATIONS

1. Bucket
2. Bucket cylinder
3. Arm
4. Arm cylinder
5. Boom
6. Boom cylinder
7. Sprocket
8. Track frame
9. Idler
10. Track shoe

MACHINE MODEL			PC60	PC60 with blade	PC60L	PC90
PERFORMANCE	Bucket capacity (m^3)	[SAE]	0.28	0.28	0.28	0.40
		[CECE]	0.25	0.25	0.25	0.35
	Travel speed (km/h)	Hi	5.0	5.0	4.6	5.0
		Lo	3.7	3.7	3.2	3.3
	Swing speed (rpm)		14.5	14.5	14.5	13.5
OPERATING WEIGHT	(kg)		6580	7180	6980	8380
ENGINE	Model		Komatsu 4D95L Diesel Engine			
	Flywheel horsepower (HP) [Rated rpm]		54.2 [2100]	54.2 [2100]	54.2 [2100]	64.1 [2300]

NOTE: Specifications are subject to change without notice.

MidWestTech | Komatsu PC60-6, PC6... Order the manual at mid-west-tech.com >