MidWestTech | Komatsu PC650-3, PC650LC-3, PC650SE-3 Hydraulic Excavator Operation...

SEAM02090306

Operation & Maintenance Manual

KOMATSU®

PC650, PC650LC-3
PC650SE-3

HYDRAULIC EXCAVATOR

SERIAL NUMBERS
PC650 -10661
PC650LC -10661 and up
PC650SE -10661

Order the manual at mid-west-tech.com >

CONTENTS

OPERATION

SAFETY HINTS ⚠ 4
GENERAL LOCATIONS AND SPECIFICATIONS 13
INSTRUMENTS AND CONTROLS 14
OPERATING THE AIR CONDITIONER 48
USING ACCUMULATORS 54
USING GREASE GUN 55
CHECK BEFORE STARTING 57
OPERATING YOUR MACHINE 65
HANDLING OF BATTERY 80
TRANSPORTATION 83
COLD WEATHER OPERATION 87

MAINTENANCE

PERIODIC MAINTENANCE 93
PRECAUTIONS FOR MAINTENANCE 94
PRECAUTIONS WHEN DISASSEMBLING MACHINE 99
BLEEDING AIR FROM CIRCUIT 101
MAINTENANCE TABLE 105
OIL FILLER AND LEVEL GAUGE POSITIONS 109
INITIAL 100 HOURS SERVICE 110
EVERY 100 HOURS SERVICE 111
INITIAL 250 HOURS SERVICE 113
EVERY 250 HOURS SERVICE 113
EVERY 500 HOURS SERVICE 121
EVERY 1000 HOURS SERVICE 125
EVERY 2000 HOURS SERVICE 128
EVERY 4000 HOURS SERVICE 133
WHEN REQUIRED 134
ADJUSTMENT 146
TROUBLE SHOOTING GUIDE 148
STORAGE 152
SERVICE METER 154
MACHINE AND ENGINE SERIAL NUMBERS 155
FUEL, COOLANT AND LUBRICANTS 156

LOADING SHOVEL 161

MidWestTech | Komatsu PC650-3, PC650LC-3, PC650SE-3 Hydraulic Excavator Opera... Order the manual at mid-west-tech.com >