Operation & Maintenance Manual

SEAM020P0700

PC20-7

HYDRAULIC EXCAVATOR

SERIAL NUMBERS PC20-35001 and up

WARNING

Unsafe use of this machine may cause serious injury or death. Operators and maintenance personnel must read this manual before operating or maintaining this machine. This manual should be kept near the machine for reference and periodically reviewed by all personnel who will come into contact with it.

NOTICE

Komatsu has Operation & Maintenance Manuals written in some other languages. If a foreign language manual is necessary, contact your local distributor for availability.

KOMATSU®

MidWestTech | Komatsu PC20-7 Hydraulic Excavator Operation & Maintenance Manual | P... Order the manual at mid-west-tech.com >

CONTENTS

OPERATION

GENERAL LOCATIONS AND SPECIFICATIONS 4
INSTRUMENTS AND CONTROLS 6
CHECK BEFORE STARTING 32
OPERATING YOUR MACHINE 38
REPLACEMENT OF BUCKET 58
SELECTION OF TRACK SHOES (STEEL SHOES ONLY) 60
HANDLING RUBBER SHOES (RUBBER SHOES ONLY) 61
COLD WEATHER OPERATION 68

MAINTENANCE

PERIODIC MAINTENANCE 73
- PERIODICAL REPLACEMENT OF SAFETY PARTS 74
- MAINTENANCE TABLE 78
- OIL FILLER AND LEVEL GAUGE POSITIONS 82
- EVERY 100 HOURS SERVICE 84
- EVERY 250 HOURS SERVICE 86
- EVERY 500 HOURS SERVICE 92
- EVERY 1000 HOURS SERVICE 94
- EVERY 2000 HOURS SERVICE 96
- WHEN REQUIRED 98

SERVICE METER 116
MACHINE AND ENGINE SERIAL NUMBERS 118
FUEL, COOLANT AND LUBRICANTS 120

MidWestTech | Komatsu PC20-7 Hydr... Order the manual at mid-west-tech.com >