Operation & Maintenance Manual

SEAM020S0703

PC25-1, PC30-7
PC40-7, PC45-1

HYDRAULIC EXCAVATOR

SERIAL NUMBERS

PC25 : 1001
PC30 : 18001
PC40 : 18001
PC45 : 1001

and up

⚠ WARNING

Unsafe use of this machine may cause serious injury or death. Operators and maintenance personnel must read this manual before operating or maintaining this machine. This manual should be kept near the machine for reference and periodically reviewed by all personnel who will come in contact with it.

KOMATSU®

MidWestTech | Komatsu PC25-1, PC30-7, PC40-7, PC45-1 Hydraulic Excavator Operation... Order the manual at mid-west-tech.com >

CONTENTS

OPERATION

GENERAL LOCATIONS AND SPECIFICATIONS 4
INSTRUMENTS AND CONTROLS 8
CHECK BEFORE STARTING 36
OPERATING YOUR MACHINE 42
REMOVAL AND INSTALLATION OF BUCKET 64
SELECTION OF TRACK SHOES (STEEL SHOES ONLY) 70
HANDLING RUBBER SHOES (RUBBER SHOES ONLY) 72
COLD WEATHER OPERATION 80

MAINTENANCE

PERIODIC MAINTENANCE 85
- PERIODICAL REPLACEMENT OF SAFETY PARTS 86
- MAINTENANCE TABLE 90
- OIL FILLER AND LEVEL GAUGE POSITIONS 94
- EVERY 100 HOURS SERVICE 96
- EVERY 250 HOURS SERVICE 98
- EVERY 500 HOURS SERVICE 104
- EVERY 1000 HOURS SERVICE 106
- EVERY 2000 HOURS SERVICE 108
- WHEN REQUIRED 110

SERVICE METER 130
MACHINE AND ENGINE SERIAL NUMBERS 132
FUEL, COOLANT AND LUBRICANTS 134

MACHINES READY FOR ATTACHMENTS 137

MidWestTech | Komatsu PC25-1, PC3... Order the manual at mid-west-tech.com >