MidWestTech | Komatsu PC50UU-1 Hydraulic Excavator Operation & Maintenance Manual...

SEAM020U0101

Operation & Maintenance Manual

PC50UU-1

HYDRAUIC EXCAVATOR

SERIAL NUMBERS PC50UU-3401 and up

KOMATSU®

Order the manual at mid-west-tech.com >

CONTENTS

OPERATION

GENERAL LOCATIONS AND SPECIFICATIONS 4
INSTRUMENTS AND CONTROLS 5
CHECK BEFORE STARTING 18
OPERATING YOUR MACHINE 23
REPLACEMENT OF BUCKET 38
COLD WEATHER OPERATION 39

MAINTENANCE

PERIODIC MAINTENANCE 43
PERIODICAL REPLACEMENT OF SAFETY PARTS 44
MAINTENANCE TABLE 46
OIL FILLER AND LEVEL GAUGE POSITIONS 49
EVERY 50 HOURS SERVICE 50
EVERY 100 HOURS SERVICE 51
INITIAL 250 HOURS SERVICE 54
EVERY 250 HOURS SERVICE 54
EVERY 500 HOURS SERVICE 59
EVERY 1000 HOURS SERVICE 62
EVERY 2000 HOURS SERVICE 64
WHEN REQUIRED 66
HANDLING RUBBER SHOES 72
TROUBLE SHOOTING GUIDE 77
SERVICE METER 80
MACHINE AND ENGINE SERIAL NUMBERS 81
FUEL, COOLANT AND LUBRICANTS 82

MidWestTech | Komatsu PC50UU-1 Hydraulic Excavator Operation & Maintenance... Order the manual at mid-west-tech.com >