SEAM02350100

Operation & Maintenance Manual

KOMATSU

GD825A-1
MOTOR GRADER

SERIAL NUMBERS
GD825A-10002 and up

MidWestTech | Komatsu GD825A-1 Motor Grader Operation & Maintenance Manual | Publi... Order the manual at mid-west-tech.com >

CONTENTS

OPERATION

FOREWORD 1
BREAKING IN YOUR NEW MACHINE 2
SAFETY HINTS - - - ⚠ 4
GENERAL LOCATIONS AND SPECIFICTIONS 11
INSTRUMENTS AND CONTROLS 12
CHECK BEFORE STARTING 35
OPERATING YOUR MACHINE 40
COLD WEATHER OPERATION 48
OPERATING OF WORK EQUIPMENT 52
REVERSING AND REPLACEMENT OF CUTTING EDGE AND END BIT 59
CHANGING TIRES 60
DRIVING ALONG ROAD 62
HANDLING OF BATTERY 63
TOWING 66
TRANSPORTATION 67

MAINTENANCE

PERIODIC MAINTENANCE 69
PRECAUTIONS FOR MAINTENANCE 70
MAINTENANCE TABLE 73
OIL FILLER AND LEVEL GAUGE POSITIONS 77
EVERY 50 HOURS SERVICE 78
INITIAL 250 HOURS SERVICE 79
EVERY 250 HOURS SERVICE 79
EVERY 500 HOURS SERVICE 88
EVERY 1000 HOURS SERVICE 93
EVERY 2000 HOURS SERVICE 99
EVERY 4000 HOURS SERVICE 103
WHEN REQUIRED 104
ADJUSTMENT 110
TROUBLE SHOOTING GUIDE 111
STORAGE 114
SERVICE METER 116
MACHINE AND ENGINE SERIAL NUMBERS 117
FUEL, COOLANT AND LUBRICANTS 118

MidWestTech | Komatsu GD825A-1 Motor Grader Operation & Maintenance Manual | Publi... Order the manual at mid-west-tech.com >