MidWestTech | Komatsu WA70-1 Wheel Loader Operation & Maintenance Manual | Public...

Operation & Maintenance Manual

SEAM04150103

WA70-1

WHEEL LOADER

SERIAL NUMBERS WA70-12001 and up

KOMATSU

Order the manual at mid-west-tech.com >

CONTENTS

OPERATION

GENERAL LOCATIONS AND SPECIFICATIONS .. 4
INSTRUMENTS AND CONTROLS 5
CHECK BEFORE STARTING 20
OPERATING YOUR MACHINE 24
ADJUSTMENT OF WORK EQUIPMENT 33
HANDLING THE TIRES 35
TOWING 38
COLD WEATHER OPERATION 39

MAINTENANCE

PERIODIC MAINTENANCE 45
PERIODICAL REPLACEMENT OF SAFETY PARTS 46
MAINTENANCE TABLE 47
OIL FILLER AND LEVEL GAUGE POSITIONS ... 50
EVERY 50 HOURS SERVICE 51
EVERY 100 HOURS SERVICE 52
EVERY 250 HOURS SERVICE 54
EVERY 500 HOURS SERVICE 60
EVERY 1000 HOURS SERVICE 63
EVERY 2000 HOURS SERVICE 68
EVERY 4000 HOURS SERVICE 70
WHEN REQUIRED 71
ADJUSTMENT 78
TROUBLE SHOOTING GUIDE 80
SERVICE METER 84
MACHINE AND ENGINE SERIAL NUMBERS 85
FUEL, COOLANT AND LUBRICANTS 86

MidWestTech | Komatsu WA70-1 Wheel Loader Operation & Maintenance Manual |... Order the manual at mid-west-tech.com >