MidWestTech | Komatsu WA200-1 Wheel Loader Operation & Maintenance Manual | Publi...

SEAM04190103

Operation & Maintenance Manual

KOMATSU®

WA200-1

WHEEL LOADER

SERIAL NUMBERS

WA200-20001 and up

Order the manual at mid-west-tech.com >

CONTENTS

OPERATION

GENERAL LOCATIONS AND SPECIFICATIONS .. 4
INSTRUMENTS AND CONTROLS 5
CHECK BEFORE STARTING 30
OPERATING YOUR MACHINE 35
ADJUSTMENT OF WORK EQUIPMENT 45
HANDLING THE TIRES 47
TOWING 50
COLD WEATHER OPERATION 51

MAINTENANCE

PERIODIC MAINTENANCE 57
PERIODICAL REPLACEMENT OF SAFETY PARTS 58
BLEEDING AIR FROM CIRCUIT 59
MAINTENANCE TABLE 60
OIL FILLER AND LEVEL GAUGE POSITIONS .. 63
EVERY 50 HOURS SERVICE 64
EVERY 100 HOURS SERVICE 65
INITIAL 250 HOURS SERVICE 66
EVERY 250 HOURS SERVICE 67
EVERY 500 HOURS SERVICE 72
EVERY 1000 HOURS SERVICE 76
EVERY 2000 HOURS SERVICE 79
EVERY 4000 HOURS SERVICE 84
WHEN REQUIRED 85
ADJUSTMENT 98
TROUBLE SHOOTING GUIDE 100
SERVICE METER 104
MACHINE AND ENGINE SERIAL NUMBERS 105
FUEL, COOLANT AND LUBRICANTS 106
ENGINE EQUIPPED WITH TURBOCHARGER 109

MidWestTech | Komatsu WA200-1 Wheel Loader Operation & Maintenance Manual |... Order the manual at mid-west-tech.com >