MidWestTech | Komatsu D20A-5, D20P-5, D20PL-5 Bulldozer Operation & Maintenance Ma...

SEAM101DOO

Operation & Maintenance Manual

KOMATSU®

D20A,P,PL-5

BULLDOZER

SES

SERIAL NUMBERS

D20A -45001
D20P -45003 and up
D20PL-45001

Order the manual at mid-west-tech.com >

CONTENTS

OPERATION

GENERAL LOCATIONS 4
SAFETY HINTS 6
OPERATOR'S COMPARTMENT 20
INSTRUMENTS AND CONTROLS 22
CHECK BEFORE STARTING 30
OPERATING YOUR MACHINE 34
COLD WEATHER OPERATION 42
BULLDOZER'S WORK 46
TIPS FOR LONGER UNDERCARRIAGE LIFE 48
REVERSING AND REPLACEMENT OF CUTTING EDGE AND END BIT 49
TRANSPORTATION 50

MAINTENANCE

PERIODIC MAINTENANCE 53
PRECAUTIONS FOR MAINTENANCE 54
MAINTENANCE TABLE 60
EVERY 50 HOURS SERVICE 64
EVERY 250 HOURS SERVICE 65
EVERY 500 HOURS SERVICE 72
EVERY 1000 HOURS SERVICE 75
EVERY 2000 HOURS SERVICE 79
WHEN REQUIRED 80
ADJUSTMENT 82
TROUBLE SHOOTING GUIDE 91
STORAGE 94
SERVICE METER 96
MACHINE AND ENGINE SERIAL NUMBERS 97
WEAR PARTS 98
SPECIFICATIONS 100
FUEL AND LUBRICANTS 104

MidWestTech | Komatsu D20A-5, D20P-5, D20PL-5 Bulldozer Operation & Maintenanc... Order the manual at mid-west-tech.com >