MidWestTech | Komatsu D57S-1 Dozer Shovel Operation & Maintenance Manual | Publicat...

SEAM135A04

Operation & Maintenance Manual

KOMATSU®

D57S-1

DOZER SHOVEL

SERIAL NUMBERS

D57S-9001 and up

Order the manual at mid-west-tech.com >

CONTENTS

OPERATION

FOREWORD 1
BREAKING IN YOUR NEW MACHINE 2
SAFETY HINTS ••• ⚠ 4
GENERAL LOCATIONS 20
OPERATOR'S COMPARTMENT 22
INSTRUMENTS AND CONTROLS 24
CHECK BEFORE STARTING 35
OPERATING YOUR MACHINE 39
COLD WEATHER OPERATION 50
BUCKET OPERATION 55
HOW TO USE INCHING PEDAL 58
ADJUSTMENT OF WORK EQUIPMENT 62
REPLACEMENT OF BUCKET TEETH 64
HANDLING OF BATTERY 65
TIPS FOR LONGER UNDERCARRIAGE LIFE ... 68
TRANSPORTATION 69

MAINTENANCE

PERIODIC MAINTENANCE 71
PRECAUTIONS FOR MAINTENANCE 72
MAINTENANCE TABLE 78
EVERY 50 HOURS SERVICE 83
EVERY 250 HOURS SERVICE 84
EVERY 500 HOURS SERVICE 90
EVERY 1000 HOURS SERVICE 94
EVERY 2000 HOURS SERVICE 99
EVERY 4000 HOURS SERVICE 108
WHEN REQUIRED 110
ADJUSTMENT 114
TROUBLE SHOOTING GUIDE 118
STORAGE 122
SERVICE METER 124
MACHINE AND ENGINE SERIAL NUMBERS ... 125
WEAR PARTS 126
SPECIFICATIONS 128
FUEL AND LUBRICANTS 130

MidWestTech | Komatsu D57S-1 Dozer Shovel Operation & Maintenance Manual | Pu... Order the manual at mid-west-tech.com >