MidWestTech | Komatsu GD511A-1, GD521A-1, GD523A-1 Motor Grader Operation & Maint...

SEAMG5110103

# Operation & Maintenance Manual

KOMATSU®

# GD511A-1, GD521A-1 GD523A-1

## MOTOR GRADER

SERIAL NUMBERS
GD511A -10031
GD521A -10044 and up
GD523A -30019

Order the manual at mid-west-tech.com >

# CONTENTS

## OPERATION


SAFETY HINTS ⚠ ..... 4
GENERAL LOCATIONS AND SPECIFICATIONS .. 16
INSTRUMENTS AND CONTROLS ..... 18
CHECK BEFORE STARTING ..... 31
OPERATING YOUR MACHINE ..... 39
OPERATING OF WORK EQUIPMENT ..... 47
REVERSING AND REPLACEMENT OF CUTTING EDGE AND END BIT ..... 56
CHANGING TIRES ..... 57
DRIVING ALONG ROAD ..... 59
TOWING ..... 60
TRANSPORTATION ..... 61
HANDLING OF BATTERY ..... 62
COLD WEATHER OPERATION ..... 65


## MAINTENANCE


PERIODIC MAINTENANCE ..... 71
PRECAUTIONS FOR MAINTENANCE ..... 72
MAINTENANCE TABLE ..... 79
OIL FILLER AND LEVEL GAUGE POSITIONS ..... 83
EVERY 50 HOURS SERVICE ..... 84
INITIAL 250 HOURS SERVICE ..... 85
EVERY 250 HOURS SERVICE ..... 85
EVERY 500 HOURS SERVICE ..... 99
EVERY 1000 HOURS SERVICE ..... 103
EVERY 2000 HOURS SERVICE ..... 114
EVERY 4000 HOURS SERVICE ..... 116
WHEN REQUIRED ..... 117
ADJUSTMENT ..... 124
TROUBLE SHOOTING GUIDE ..... 125
STORAGE ..... 128
SERVICE METER ..... 130
MACHINE AND ENGINE SERIAL NUMBERS ..... 131
FUEL, COOLANT AND LUBRICANTS ..... 132





MidWestTech | Komatsu GD511A-1, GD521A-1, GD523A-1 Motor Grader Operation... Order the manual at mid-west-tech.com >