MidWestTech | Komatsu GD511A-1, GD521A-1, GD523A-1 Motor Grader Operation & Maint...

Operation & Maintenance Manual

SEAMG5110104

GD511A-1
GD521A-1
GD523A-1

MOTOR GRADER

SERIAL NUMBERS GD511A-10243
GD521A-10075 and up
GD523A-30099

KOMATSU®

Order the manual at mid-west-tech.com >

CONTENTS

OPERATION

SAFETY HINTS · · · ⚠ 4
GENERAL LOCATIONS AND SPECIFICATIONS .. 16
INSTRUMENTS AND CONTROLS 18
CHECK BEFORE STARTING 31
OPERATING YOUR MACHINE 39
OPERATING OF WORK EQUIPMENT 47
REVERSING AND REPLACEMENT OF CUTTING EDGE AND END BIT 56
CHANGING TIRES 57
DRIVING ALONG ROAD 59
TOWING 60
TRANSPORTATION 61
HANDLING OF BATTERY 62
COLD WEATHER OPERATION 65

MAINTENANCE

PERIODIC MAINTENANCE 71
PRECAUTIONS FOR MAINTENANCE 72
MAINTENANCE TABLE 79
OIL FILLER AND LEVEL GAUGE POSITIONS 83
EVERY 50 HOURS SERVICE 84
EVERY 250 HOURS SERVICE 85
EVERY 500 HOURS SERVICE 99
EVERY 1000 HOURS SERVICE 103
EVERY 2000 HOURS SERVICE 114
EVERY 4000 HOURS SERVICE 116
WHEN REQUIRED 117
ADJUSTMENT 124
TROUBLE SHOOTING GUIDE 125
STORAGE 128
SERVICE METER 130
MACHINE AND ENGINE SERIAL NUMBERS 131
FUEL, COOLANT AND LUBRICANTS 132

MidWestTech | Komatsu GD511A-1, GD521A-1, GD523A-1 Motor Grader Operation &... Order the manual at mid-west-tech.com >