SEBM000704

SHOP MANUAL

KOMATSU®

HD325-6
HD405-6

MACHINE MODEL	SERIAL NUMBER
HD325-6 (2WD)	**5001 and up**
HD325-6W (4WD)	**5001 and up**
HD405-6	**1001 and up**

- This shop manual may contain attachments and optional equipment that are not available in your area. Please consult your local Komatsu distributor for those items you may require. Materials and specifications are subject to change without notice.

- HD325-6, HD405-6 mount the SA6D140-1 or SAA6D140-2 engine.
  For details of the engine, see the 6D140-1 or 6D140-2 Series Engine Shop Manual.

MidWestTech | Komatsu HD325-6, HD405-6 Rock Truck Service Manual | Publication SEBM000704
Order the manual at mid-west-tech.com >

The affected pages are indicated by the use of the following marks. It is requested that necessary actions be taken to these pages according to the table below.

Mark	Indication	Action required
○	Page to be newly added	Add
●	Page to be replaced	Replace
( )	Page to be deleted	Discard

Pages having no marks are those previously revised or made additions.

LIST OF REVISED PAGES


Mark	Page	Revision number
●	00-1	④
	00-2	①
●	00-2-1	④
●	00-2-2	④
●	00-2-3	④
●	00-2-4	④
	00-3	
	00-4	
	00-5	
	00-6	
	00-7	
	00-8	
	00-9	
	00-10	
	00-11	
	00-12	
	00-13	
	00-14	
	00-15	
	00-16	
	00-17	
	00-18	
○	00-19	
●	01-1	④
●	01-2	④
●	01-3	④
●	01-4	④
●	01-5	④
●	01-6	④
●	01-7	④
○	01-8	④
○	01-9	④
○	01-10	④
○	01-11	④
○	01-12	④
○	01-13	④
●	10-1	④
●	10-2	④
●	10-3	④
●	10-4	④
●	10-4-1	④
	10-5	
	10-6	
	10-7	
	10-8	
	10-9	
	10-10	②
	10-10-1	②
	10-11	
	10-12	
	10-13	
	10-14	
	10-15	
	10-16	
	10-17	
	10-18	
	10-19	
	10-20	
	10-21	
	10-22	
	10-23	
	10-24	
	10-25	
	10-26	
●	10-27	④
	10-27-1	②
	10-28	
●	10-29	④
○	10-29-1	④
●	10-29-2	④
○	10-29-3	④
●	10-30	
●	10-31	④
	10-32	
	10-33	
	10-34	
	10-35	
	10-36	
	10-37	
	10-38	
	10-39	
	10-40	
	10-41	
	10-42	
	10-43	
	10-44	
	10-45	
●	10-46	④
○	10-46-1	④
●	10-47	④
●	10-49	④
●	10-50	④
●	10-50-1	④
●	10-50-2	④
○	10-50-3	④
○	10-50-4	④
○	10-50-5	④
○	10-50-6	④
	10-51	
	10-52	
○	10-52-1	④
○	10-52-2	④
	10-53	
	10-54	
	(10-55)	
●	10-56	④
	10-57	
	10-58	
	10-59	
	10-60	
	10-61	
	10-62	
	10-63	
	10-64	②
	10-65	
	10-66	
	10-67	
	10-68	
	10-69	
	10-70	
	10-71	
●	10-72	④
●	10-73	④
○	10-73-1	④
○	10-73-2	④
	10-74	
	10-76	
	10-76-1	②
●	10-76-2	④
●	10-76-3	④
●	10-76-4	④
●	10-76-5	④
●	10-76-6	④
●	10-76-7	④
○	10-76-8	④
	10-77	
	10-78	
	10-79	
	10-80	
	10-81	
	10-82	
	10-83	
	10-84	
	10-85	
	10-86	
	10-87	
	10-88	
	10-89	
	10-90	
	10-91	
●	10-94	④
	10-95	
	10-97	
○	10-98-2	④
○	10-98-3	④
○	10-98-5	④
○	10-98-8	④
○	10-98-9	④
	10-99	②
	10-100	②
	10-101	②
	10-102	②
	10-103	
	10-104	
	10-105	
	10-106	
	10-107	
○	10-107-1	④
○	10-107-2	④
○	10-107-3	④
	10-108	
	10-109	
	10-110	
	10-111	
	10-112	
	10-113	
	10-114	
	10-115	
	10-116	
	10-117	
	10-118	
	10-119	
	10-120	
	10-121	
	10-122	
	10-123	
	10-124	
	10-125	
	10-126	
	10-127	
	10-128	
	10-129	
	10-130	
	10-131	
	10-132	
	10-133	
	10-134	
	10-135	
	10-136	②
	10-137	
	10-138	②
	10-138-1	②
	10-139	

056606

MidWestTech | Komatsu HD325-6, HD405-6 Rock Truck Service Manual | Publication... Order the manual at mid-west-tech.com >

ELECTRICAL CIRCUIT DIAGRAM

HD325-6: Serial No.: 5001 – 5291
HD325-6W: Serial No.: 5001 – 5291



MidWestTech | Komatsu HD325-6, HD405-6 Rock Truck Service Manual | Publication SEBM000704
Order the manual at mid-west-tech.com >