SEBM001500

SHOP MANUAL

KOMATSU®

WA30-5

WHEEL LOADER

MACHINE MODEL	SERIAL No.
WA30-5	**15001 and up**

KOMATSU®

MidWestTech | Komatsu WA30-5 Wheel Loader Service Manual | Publication SEBM001500

Order the manual at mid-west-tech.com >

WEIGHT TABLE


⚠ This weight table is a guide for use when transporting or handling components.

Unit : kg

Serial Numbers		15001 and up
Engine		155
Radiator		12
Fuel tank		21.5
HST pump (include charge pump)		42.5
HST motor		29
Transfer		68
Front drive shaft		8.5
Rear drive shaft		3.6
Front axle		127
Rear axle		123
Axle support		23.2
Wheel	(1 piece)	12.7
Tire	(1 piece)	30
Steering valve		8.2
Steering cylinder		8
Engine hood		13.5
Floor		18
Operator's seat Ass'y		9
Canpy		47
Counterweight		400
Front frame		181
Rear frame		210
Hydraulic tank		24.5
Work equipment - steering pump		2.3
Main control valve		9
Lift cylinder	(1 piece)	19.2
Dump cylinder		14
Bucket link		10
Bellcrank		51
Lift arm (include bushing)		151
Bucket		147

MidWestTech | Komatsu WA30-5 Wheel Loader Service Manual | Publication SEBM00... Order the manual at mid-west-tech.com >

ELECTRICAL CIRCUIT DIAGRAM



MidWestTech | Komatsu WA30-5 Wheel Loader Service Manual | Publication SEBM001500

Order the manual at mid-west-tech.com >