SEBM0120C07

SHOP MANUAL

KOMATSU®

D40A,P-3
D41A,E,P-3
D41A-3A

MACHINE MODEL	SERIAL No.
D40A-3	**60001 and up**
D40P-3	**60001 and up**
D40PL-3	**60001 and up**
D40PLL-3	**60001 and up**
D41A-3	**60001 and up**
D41E-3	**60001 and up**
D41P-3	**60001 and up**
D41A-3A	**60001 and up**

- This shop manual may contain attachments and optional equipment that are not available in your area. Please consult your local Komatsu distributor for those items you may require. Materials and specifications are subject to change without notice.

- D40 · 41-3 mount the 6D105-1 engine.
  For details of the engine, see the 105 Series Engine Shop Manual.

MidWestTech | Komatsu D40A, D40AP-3, D41A, D41AE, D41AP-3, D41A-3A Crawler Dozer Service Manual | Publication SEBM0120C07
Order the manual at mid-west-tech.com >

CONTENTS

No. of page

01 GENERAL 01-1

10 ENGINE
- 11 STRUCTURE AND FUNCTION 11-1
- 12 TESTING AND ADJUSTING 12-1
- 13 DISASSEMBLY AND ASSEMBLY 13-1

20 POWER TRAIN
- 21 STRUCTURE AND FUNCTION 21-1
- 22 TESTING AND ADJUSTING 22-1
- 23 DISASSEMBLY AND ASSEMBLY 23-1
- 24 MAINTENANCE STANDARD 24-1

30 UNDERCARRIAGE
- 31 STRUCTURE AND FUNCTION 31-1
- 33 DISASSEMBLY AND ASSEMBLY 33-1
- 34 MAINTENANCE STANDARD 34-1


60 HYDRAULIC SYSTEM
- 61 STRUCTURE AND FUNCTION 61-1
- 62 TESTING AND ADJUSTING 62-1
- 63 DISASSEMBLY AND ASSEMBLY 63-1
- 64 MAINTENANCE STANDARD 64-1

70 WORK EQUIPMENT
- 71 STRUCTURE AND FUNCTION 71-1
- 73 DISASSEMBLY AND ASSEMBLY 73-1
- 74 MAINTENANCE STANDARD 74-1

90 OTHERS
- 90 ELECTRICAL SYSTEM 90-1

MidWestTech | Komatsu D40A, D40AP-3, D41A, D41AE, D41AP-3, D41A-3A Crawler... Order the manual at mid-west-tech.com >

REGULATION OF EC INCLUSION



SAD00512

MidWestTech | Komatsu D40A, D40AP-3, D41A, D41AE, D41AP-3, D41A-3A Crawler Dozer Service Manual | Publication SEBM0120C07

Order the manual at mid-west-tech.com >