SEBM0141C01

SHOP MANUAL

KOMATSU®

D60S-7
D65S-7

MACHINE MODEL	SERIAL NO.
D60S-7	40001 and up
D65S-7	40001 and up

MidWestTech | Komatsu D60S-7, D65S-7 Crawler Dozer Service Manual | Publication SEBM0141C01

Order the manual at mid-west-tech.com >

Mark	Page	Revision number	Mark	Page	Revision number	Mark	Page	Revision number	Mark	Page	Revision number	Mark	Page	Revision number
○	23-3	①	○	23-60	①	○	23-119	①		31-8		○	63-8	①
○	23-4	①	○	23-61	①	○	23-120	①		31-9		○	63-9	①
○	23-5	①	○	23-62	①	○	23-122	①		31-10		○	63-10	①
○	23-6	①	○	23-63	①	○	23-123	①	○	33-1	①	○	63-11	①
○	23-7	①	○	23-64	①	○	23-124	①	○	33-2	①	○	63-12	①
○	23-8	①	○	23-65	①	○	23-125	①	○	33-4	①	○	63-13	①
○	23-10	①	○	23-66	①	○	23-126	①	○	33-5	①	○	63-14	①
○	23-11	①	○	23-67	①	○	23-128	①	○	33-6	①	○	63-15	①
○	23-12	①	○	23-68	①	○	23-129	①	○	33-7	①	○	63-16	①
○	23-13	①	○	23-69	①	○	23-130	①	○	33-8	①	○	63-17	①
○	23-14	①	○	23-70	①	○	23-131	①	○	33-9	①	○	63-18	①
○	23-15	①	○	23-71	①	○	23-132	①	○	33-10	①	○	63-19	①
○	23-16	①	○	23-72	①	○	23-134	①	○	33-11	①		64-1	
○	23-17	①	○	23-73	①	○	23-135	①		34-1			64-3	
○	23-18	①	○	23-74	①	○	23-136	①		34-3			64-4	
○	23-19	①	○	23-75	①	○	23-137	①		34-4			64-5	
○	23-20	①	○	23-76	①	○	23-138	①		34-5			64-6	
○	23-21	①	○	23-77	①		24-1		●	34-6	①		64-7	
○	23-22	①	○	23-78	①		24-3			34-7			64-8	
○	23-23	①	○	23-79	①		24-4			34-8			64-9	
○	23-24	①	○	23-80	①		24-5		●	34-9	①		64-10	
○	23-25	①	○	23-82	①		24-6			34-10			64-11	
○	23-26	①	○	23-83	①	●	24-7	①		34-12			71-1	
○	23-28	①	○	23-84	①		24-8			34-13			71-2	
○	23-29	①	○	23-85	①		24-10			34-14			71-3	
○	23-30	①	○	23-86	①	●	24-11	①		34-15			71-4	
○	23-31	①	○	23-87	①		24-12			34-16			71-5	
○	23-32	①	○	23-88	①		24-13			34-17		○	73-1	①
○	23-33	①	○	23-90	①		24-14			34-18		○	73-2	①
○	23-34	①	○	23-91	①		24-15			34-19		○	73-3	①
○	23-35	①	○	23-92	①		24-16			34-20		○	73-4	①
○	23-36	①	○	23-93	①		24-18			61-1		○	73-5	①
○	23-37	①	○	23-94	①		24-19			61-2		○	73-6	①
○	23-38	①	○	23-95	①		24-20			61-3		○	73-7	①
○	23-39	①	○	23-96	①		24-21			61-4		○	73-8	①
○	23-40	①	○	23-97	①		24-22			61-5		○	73-9	①
○	23-41	①	○	23-98	①		24-23			61-6		○	73-10	①
○	23-42	①	○	23-100	①		24-24			61-7		○	73-11	①
○	23-43	①	○	23-101	①		24-25			61-8		○	73-12	①
○	23-44	①	○	23-102	①	●	24-26	①		61-9		○	73-13	①
○	23-45	①	○	23-103	①	●	24-27	①		61-10		○	73-14	①
○	23-46	①	○	23-104	①		24-28			61-11		○	73-15	①
○	23-47	①	○	23-105	①	●	24-29	①		61-12			74-1	
○	23-48	①	○	23-106	①		24-30			61-13			74-3	
○	23-49	①	○	23-107	①		24-31			61-14			74-4	
○	23-50	①	○	23-108	①		24-32			61-15		●	74-5	①
○	23-51	①	○	23-109	①	●	24-33	①	○	62-1	①		74-6	
○	23-52	①	○	23-110	①		24-34		○	62-2	①		91-1	
○	23-53	①	○	23-111	①		31-1		○	63-1	①		91-3	
○	23-54	①	○	23-112	①		31-2		○	63-2	①			
○	23-55	①	○	23-113	①		31-3		○	63-3	①			
○	23-56	①	○	23-114	①		31-4		○	63-4	①			
○	23-57	①	○	23-115	①		31-5		○	63-5	①			
○	23-58	①	○	23-116	①		31-6		○	63-6	①			
○	23-59	①	○	23-118	①		31-7		○	63-7	①			

MidWestTech | Komatsu D60S-7, D65S-7 Crawler Dozer Service Manual | Publication... Order the manual at mid-west-tech.com >

CONTENTS

No. of page

GENERAL 01-1

ENGINE

11 STRUCTURE AND FUNCTION 11-1
12 TESTING AND ADJUSTING 12-1
13 DISASSEMBLY AND ASSEMBLY 13-1

POWER TRAIN

21 STRUCTURE AND FUNCTION 21-1
22 TESTING AND ADJUSTING 22-1
23 DISASSEMBLY AND ASSEMBLY 23-1
24 MAINTENANCE STANDARD 24-1

UNDERCARRIAGE

31 STRUCTURE AND FUNCTION 31-1
33 DISASSEMBLY AND ASSEMBLY 33-1
34 MAINTENANCE STANDARD 34-1

HYDRAULIC SYSTEM

61 STRUCTURE AND FUNCTION 61-1
62 TESTING AND ADJUSTING 62-2
63 DISASSEMBLY AND ASSEMBLY 63-1
64 MAINTENANCE STANDARD 64-1

WORK EQUIPMENT


71 STRUCTURE AND FUNCTION 71-1
73 DISASSEMBLY AND ASSEMBLY 73-1
74 MAINTENANCE STANDARD 74-1

OTHERS

91 ELECTRICAL SYSTEM 91-1

MidWestTech | Komatsu D60S-7, D65S-7 Crawler Dozer Service Manual | Publication... Order the manual at mid-west-tech.com >

ELECTRICAL WIRING DIAGRAM



MidWestTech | Komatsu D60S-7, D65S-7 Crawler Dozer Service Manual | Publication SEBM0141C01
Order the manual at mid-west-tech.com >