SEBM014207

SHOP MANUAL

KOMATSU®

PC1100-6
PC1100SP-6
PC1100LC-6

MACHINE MODEL	SERIAL NUMBER
PC1100-6	10001 and up
PC1100SP-6	10001 and up
PC1100LC-6	10001 and up

- This shop manual may contain attachments and optional equipment that are not available in your area. Please consult your local Komatsu distributor for those items you may require. Materials and specifications are subject to change without notice.

- PC1100-6 mount the SAA6D170-2 engine.
  For details of the engine, see the 6D170-2 Series Engine Shop Manual.

MidWestTech | Komatsu PC1100-6, PC1100SP-6, PC1100LC-6 Hydraulic Excavator Service Manual | Publication SEBM014207
Order the manual at mid-west-tech.com >

CONTENTS

No. of page

01 GENERAL 01-1

10 STRUCTURE AND FUNCTION 10-1

20 TESTING AND ADJUSTING 20-1


30 DISASSEMBLY AND ASSEMBLY 30-1

40 MAINTENANCE STANDARD 40-1

90 OTHERS 90-1

MidWestTech | Komatsu PC1100-6, PC1100SP-6, PC1100LC-6 Hydraulic Excavator S... Order the manual at mid-west-tech.com >

ELECTRICAL CIRCUIT DIAGRAM (1/4)



MidWestTech | Komatsu PC1100-6, PC1100SP-6, PC1100LC-6 Hydraulic Excavator Service Manual | Publication SEBM014207

Order the manual at mid-west-tech.com >