SEBM014508

SHOP MANUAL

KOMATSU®

PC400, 400LC-6
PC450, 450LC-6

MACHINE MODEL	SERIAL NUMBER
PC400-6	**32001 and up**
PC400LC-6	**32001 and up**
PC450-6	**12001 and up**
PC450LC-6	**12001 and up**

- This shop manual may contain attachments and optional equipment that are not available in your area. Please consult your local Komatsu distributor for those items you may require. Materials and specifications are subject to change without notice.

- PC400, 450-6 mount the SA6D125-2 engine.
  For details of the engine, see the 125-2 Series Engine Shop Manual.

MidWestTech | Komatsu PC400-6, 400LC-6, PC450-6, 450LC-6 Hydraulic Excavator Service Manual | Publication SEBM014508

Order the manual at mid-west-tech.com >

CONTENTS

No. of page

01 GENERAL 01-1

10 STRUCTURE AND FUNCTION 10-1

20 TESTING AND ADJUSTING 20-1


30 DISASSEMBLY AND ASSEMBLY 30-1

40 MAINTENANCE STANDARD 40-1

90 OTHERS 90-1

MidWestTech | Komatsu PC400-6, 400LC-6, PC450-6, 450LC-6 Hydraulic Excavator S... Order the manual at mid-west-tech.com >

ELECTRIC CIRCUIT DIAGRAM (1/3)



MidWestTech | Komatsu PC400-6, 400LC-6, PC450-6, 450LC-6 Hydraulic Excavator Service Manual | Publication SEBM014508

Order the manual at mid-west-tech.com >