SEBM0170A07R

SHOP MANUAL

KOMATSU®

D150A-1

D155A-1

MACHINE MODEL	SERIAL No.
D150A-1	8408 and up
D155A-1	15001 and up

MidWestTech | Komatsu D150A-1, D155A-1 Crawler Dozer Service Manual | Publication SEBM0170A07R

Order the manual at mid-west-tech.com >

CONTENTS

No. of page

GENERAL 01-1

ENGINE

11 STRUCTURE AND FUNCTION 11-1
12 TESTING AND ADJUSTING 12-1
13 DISASSEMBLY AND ASSEMBLY 13-1

POWER TRAIN

21 STRUCTURE AND FUNCTION 21-1
22 TESTING AND ADJUSTING 22-1
23 DISASSEMBLY AND ASSEMBLY 23-1
24 MAINTENANCE STANDARD 24-1

UNDERCARRIAGE

31 STRUCTURE AND FUNCTION 31-1
33 DISASSEMBLY AND ASSEMBLY 33-1
34 MAINTENANCE STANDARD 34-1

HYDRAULIC SYSTEM

61 STRUCTURE AND FUNCTION 61-1
62 TESTING AND ADJUSTING 62-1
63 DISASSEMBLY AND ASSEMBLY 63-1
64 MAINTENANCE STANDARD 64-1

WORK EQUIPMENT

71 STRUCTURE AND FUNCTION 71-1
72 TESTING AND ADJUSTING 72-1
73 DISASSEMBLY AND ASSEMBLY 73-1
74 MAINTENANCE STANDARD 74-1

OTHERS

90 ELECTRICAL SYSTEM 90-1

MidWestTech | Komatsu D150A-1, D155A-1 Crawler Dozer Service Manual | Publicati... Order the manual at mid-west-tech.com >

The affected pages are indicated by the use of the following marks. It is requested that necessary actions be taken to these pages according to the table below.

Mark	Indication	Action required
○	Page to be newly added	Add
●	Page to be replaced	Replace
( )	Page to be deleted	Discard

Pages having no marks are those previously revised or made additions.

LIST OF REVISED PAGES

Mark	Page	Time of revision	Mark	Page	Time of revision	Mark	Page	Time of revision	Mark	Page	Time of revision	Mark	Page	Time of revision
•	00- 1	⑦		01- 8	④		01-23	④		12-11			13-15	
•	00- 2	⑦		01- 8-1	③		01-24			12-12			13-16	
•	00- 2-1	⑦		01- 8-2	③					12-13			13-17	
•	00- 2-2	⑦		01- 9	④		11- 1	③		12-14			13-18	
•	00- 2-3	⑦		01-10	④		11- 2	④		12-15			13-19	
•	00- 2-4	⑦		01- 9-1	④		11- 3	④		12-16			13-20	
•	00- 2-5	⑦		01- 9-3	④		11- 3-1	④					13-21	
○	00- 2-6	⑦		01- 9-4	④		11- 3-2	④					13-22	
•	00- 3			01- 9-5	④		11- 3-3	④		13- 1	⑤		13-23	
•	00- 4			01- 9-6	④		11- 4	③		13- 2			13-24	
•	00- 5			01- 9-7	④		11- 5	③		13- 3			13-25	
•	00- 6			01- 9-8	④		11- 6	④		13- 4			13-26	
•	00- 7			01-10			11- 7	④		13- 5			13-27	
•	00- 8			01-11	④					13- 6			13-28	
•	00- 9			01-12	④					13- 7			13-29	
•	00-10			01-13	④		12- 1	⑤		13- 8			13-30	
	(00-11)			01-14	③		12- 2	⑤		13- 9			13-31	
				01-15	④		12- 2-1	⑤		13-10			13-32	
	01- 1			01-15-1	③		12- 2-2	⑤		13-11			13-33	
	01- 2	③		01-15-2	④		12- 2-3	⑤		13-12			13-34	
	01- 2-1	③		01-16	③		12- 3	⑤		13-13			13-35	
	01- 3			01-17	④		12- 4			13-13-1	⑤		13-36	
	01- 4	③		01-18	④		12- 5	⑤		13-13-2	⑤		13-37	
	01- 4-1	④		01-19	⑤		12- 6	⑤		13-13-3	⑤		13-38	
	01- 5	④	•	01-20	⑦		12- 7			13-13-4	⑤		13-39	
	01- 5-1	④	○	01-20-1	⑦		12- 8	⑤		13-13-5	⑤		13-40	
	01- 6	④		01-21	④		12- 9			13-13-6	⑤		13-41	
	01- 7	④		01-22	④		12-10			13-14			13-42	

MidWestTech | Komatsu D150A-1, D155A-1 Crawler Dozer Service Manual | Publicati... Order the manual at mid-west-tech.com >

LIST OF REVISED PAGES

Mark	Page	Time of revision
	13-43	
	13-44	
	13-45	
	13-46	
	13-47	
	13-48	1
	13-49	
	13-50	
	13-51	
	13-52	
	13-53	5
	13-53-1	5
	13-53-2	5
	13-53-3	5
	13-53-4	5
	13-53-5	5
	13-53-6	5
	13-53-7	5
	13-53-8	5
	13-53-9	5
	13-53-10	5
	13-53-11	5
	13-53-12	5
	13-53-13	5
	13-53-14	5
	13-53-15	5
	13-53-16	5
	13-53-17	5
	13-53-18	5
	13-53-19	5
	13-53-20	5
	13-53-21	5
	13-53-22	5
	13-53-23	5
	13-53-24	5
	13-53-25	5
	13-53-26	5
	13-53-27	5
	13-53-28	5
	13-53-29	5
	13-53-30	5
	13-53-31	5
	13-53-32	5
	13-54	5
	13-55	5
	13-56	
	13-57	
	13-58	
	13-59	
	13-60	
	13-61	5
	13-62	5
	13-63	5
	13-64	
	13-65	
	13-66	
	13-67	
	13-68	
	13-69	
	13-70	
	13-70-2	5
	13-70-3	5
	13-70-4	5
	13-70-5	5
	13-70-6	5
	13-70-7	5
	13-70-8	5
	13-70-9	5
	13-70-10	5
	13-70-11	5
	13-70-12	5
	13-70-14	5
	13-70-15	5
	13-70-16	5
	13-70-17	5
	13-70-18	5
	13-70-19	5
	13-70-20	5
	13-70-21	5
	13-70-22	5
	13-70-23	5
	13-70-24	5
	13-72	5
	13-73	5
	13-74	5
	13-75	
	13-76	
	21- 1	7
	21- 2	
	21- 3	
	21- 4	
	21- 5	
	(21- 6)	
	(21- 7)	
	(21- 8)	
	(21- 9)	
	21-10	1
	21-11	
	21-12	
	21-13	
	21-14	
	21-15	1
	21-16	1
	21-17	
	21-18	1
	21-19	1
	21-20	
	21-21	
	21-22	
	21-23	
	21-24	
	21-25	
	21-26	
	21-27	
	21-27-1	1
○	21-27-2	7
•	21-28	7
	21-29	
	21-30	
•	21-31	7
	21-32	
•	21-33	7
	21-34	
	21-35	
	21-36	
	21-37	
	21-38	
	21-39	
	21-40	
	21-41	
	21-42	4
	21-42-1	4
•	21-43	7
•	21-44	7
•	21-45	7
•	21-46	7
•	21-47	7
•	21-48	7
•	21-49	7
•	21-50	7
•	21-51	7
	(21-51-1)	
	(21-51-2)	
•	21-52	7
	(21-53)	
	(21-53-1)	
	(21-53-2)	
•	21-54	7
○	21-55	7
•	21-56	7
•	21-57	7
•	21-58	7
○	21-59	7
•	21-60	7
•	21-61	7
•	21-62	7
	(21-62-1)	
	(21-62-2)	
•	21-63	7
	(21-63-1)	
•	21-64	7
	(21-65)	
•	21-66	7
•	21-67	7
•	21-68	7
	(21-68-1)	
	(21-68-2)	
	(21-68-4)	
	(21-68-5)	
	(21-68-6)	
	(21-68-7)	
	(21-68-8)	
•	21-69	7
	(21-69-1)	
•	21-70	7
•	21-71	7
•	21-72	7
	(21-72-1)	
	(21-72-2)	
	(21-72-3)	
•	21-73	7
	(21-73-1)	
•	21-74	7
•	21-75	7
•	21-76	7
•	21-77	7
	(21-77-1)	
	(21-77-2)	
	(21-77-3)	
	(21-77-4)	
	(21-77-5)	
	(21-77-6)	
•	21-78	7
•	21-79	7
•	21-80	7
○	21-82	7
○	21-83	7
○	21-84	7

MidWestTech | Komatsu D150A-1, D155A-1 Crawler Dozer Service Manual | Publicati... Order the manual at mid-west-tech.com >