SEBM017111

SHOP MANUAL

KOMATSU®

PC600-6
PC600LC-6

MACHINE MODEL	SERIAL NUMBER
PC600-6	**10001 and up**
PC600LC-6	**10001 and up**

- This shop manual may contain attachments and optional equipment that are not available in your area. Please consult your local Komatsu distributor for those items you may require. Materials and specifications are subject to change without notice.
- PC600, PC600LC-6 (Serial No.: 10001 – 11000) mount the CUMMINS N14-C420 engine. For details of the engine, see the CUMMINS N14-C420 Series Engine Shop Manual.
- PC600, PC600LC-6 (Serial No.: 11001 and up) mount the KOMATSU SA6D140E-3 engine. For details of the engine, see the 140-3 Series Engine Shop Manual.

MidWestTech | Komatsu PC600-6, PC600LC-6 Hydraulic Excavator Service Manual | Publication SEBM017111
Order the manual at mid-west-tech.com >

CONTENTS

No. of page

01 GENERAL 01-1

10 STRUCTURE AND FUNCTION 10-1

20 TESTING AND ADJUSTING 20-1


30 DISASSEMBLY AND ASSEMBLY 30-1

40 MAINTENANCE STANDARD 40-1

90 OTHERS 90-1

MidWestTech | Komatsu PC600-6, PC600LC-6 Hydraulic Excavator Service Manual |... Order the manual at mid-west-tech.com >

ELECTRIC CIRCUIT DIAGRAM (1/3)



MidWestTech | Komatsu PC600-6, PC600LC-6 Hydraulic Excavator Service Manual | Publication SEBM017111

Order the manual at mid-west-tech.com >