SEBM0176A01

SHOP MANUAL

KOMATSU®

D155C-1

MACHINE MODEL SERIAL No.

D155C-1 15001 and up

MidWestTech | Komatsu D155C-1 Bulldozer Service Manual | Publication SEBM0176A01

Order the manual at mid-west-tech.com >

CONTENTS

No. of page

01 GENERAL 01-1

10 ENGINE

11 STRUCTURE AND FUNCTION 11-1
12 TESTING AND ADJUSTING 12-1
13 DISASSEMBLY AND ASSEMBLY 13-1

20 POWER TRAIN

21 STRUCTURE AND FUNCTION 21-1
22 TESTING AND ADJUSTING 22-1
24 MAINTENANCE STANDARD 24-1

30 UNDERCARRIAGE

31 STRUCTURE AND FUNCTION 31-1
34 MAINTENANCE STANDARD 34-1

60 HYDRAULIC SYSTEM

61 STRUCTURE AND FUNCTION 61-1
62 TESTING AND ADJUSTING 62-1
63 DISASSEMBLY AND ASSEMBLY 63-1
64 MAINTENANCE STANDARD 64-1

70 WORK EQUIPMENT

71 STRUCTURE AND FUNCTION 71-1
73 DISASSEMBLY AND ASSEMBLY 73-1
74 MAINTENANCE STANDARD 74-1


90 OTHERS

91 ELECTRICAL SYSTEM 91-1

MidWestTech | Komatsu D155C-1 Bulldozer Service Manual | Publication SEBM0176... Order the manual at mid-west-tech.com >

POWER LINE ON THE WINCH

1. Neutral Position of the Hi-Low Lever



Winch specifications

Particulars			
PTO reduction ratio			1.256
Winch speed reduction ratio	Winding	L	43.110
		H	19.133
	Unwinding	L	52.844
		H	23.514
Drum revolutions (rpm)	Winding	L	36.93
		H	82.99
	Unwinding	L	30.13
		H	67.70
Hook speed (m/min.)	Winding	L	6.0
		H	13.8
	Unwinding	L	4.8
		H	11.1

MidWestTech | Komatsu D155C-1 Bulldozer Service Manual | Publication SEBM0176A01 Order the manual at mid-west-tech.com >