SEBM019105

SHOP MANUAL

KOMATSU®

PC1800-6

MACHINE MODEL	SERIAL NUMBER
PC1800-6	**10002 and up**

- This shop manual may contain attachments and optional equipment that are not available in your area. Please consult your local Komatsu distributor for those items you may require. Materials and specifications are subject to change without notice.

- PC1800-6 mounts the SAA6D140-2 engine.
  For details of the engine, see the 6D140-2 Series Engine Shop Manual.

MidWestTech | Komatsu PC1800-6 Hydraulic Excavator Service Manual | Publication SEBM019105
Order the manual at mid-west-tech.com >

CONTENTS

No. of page

01 GENERAL 01-1

10 STRUCTURE AND FUNCTION 10-1

20 TESTING AND ADJUSTING 20-1


30 DISASSEMBLY AND ASSEMBLY 30-1

40 MAINTENANCE STANDARD 40-1

90 OTHERS 90-1

MidWestTech | Komatsu PC1800-6 Hydraulic Excavator Service Manual | Publication... Order the manual at mid-west-tech.com >

HYDRAULIC CIRCUIT DIAGRAM (LOADING SHOVEL)



MidWestTech | Komatsu PC1800-6 Hydraulic Excavator Service Manual | Publication SEBM019105

Order the manual at mid-west-tech.com >