SEBM02010505

SHOP MANUAL

KOMATSU®

PC60-5
PC60L-5
PC60U-5

MACHINE MODEL	SERIAL No.
PC60-5	**20501 and up**
PC60L-5	**7501 and up**
PC60U-5	**4501 and up**

- This shop manual may contain attachments and optional equipment that are not available in your area. Please consult your local Komatsu distributor for those items you may require. Materials and specifications are subject to change without notice.

- PC60, 60L and 60U mount the 4D95L-1 engine.
  For details of the engine, see the 95 series engine Shop Manual.

MidWestTech | Komatsu PC60-5, PC60L-5, PC60U-5 Excavator Service Manual | Publication SEBM02010505
Order the manual at mid-west-tech.com >

CONTENTS

10 ENGINE — No. of page

11 STRUCTURE AND FUNCTION 11-1
12 TESTING AND ADJUSTING 12-1
13 DISASSEMBLY AND ASSEMBLY 13-1

20 POWER TRAIN

21 STRUCTURE AND FUNCTION 21-1
23 DISASSEMBLY AND ASSEMBLY 23-1
24 MAINTENANCE STANDARD 24-1

30 UNDERCARRIAGE

31 STRUCTURE AND FUNCTION 31-1
33 DISASSEMBLY AND ASSEMBLY 33-1
34 MAINTENANCE STANDARD 34-1

60 HYDRAULIC SYSTEM

61 STRUCTURE AND FUNCTION 61-1
62 TESTING AND ADJUSTING 62-1
63 DISASSEMBLY AND ASSEMBLY 63-1
64 MAINTENANCE STANDARD 64-1

70 WORK EQUIPMENT

73 DISASSEMBLY AND ASSEMBLY 73-1

80 ELECTRICAL SYSTEM

81 STRUCTURE AND FUNCTION 81-1
82 TESTING AND ADJUSTING 82-1

MidWestTech | Komatsu PC60-5, PC60L-5, PC60U-5 Excavator Service Manual | Pub... Order the manual at mid-west-tech.com >

The affected pages are indicated by the use of the following marks. It is requested that necessary actions be taken to these pages according to the table below.

Mark	Indication	Action required
○	Page to be newly added	Add
●	Page to be replaced	Replace
( )	Page to be deleted	Discard

Pages having no marks are those previously revised or made additions.


LIST OF REVISED PAGES

Mark	Page	Revision number	Mark	Page	Revision number	Mark	Page	Revision number	Mark	Page	Revision number	Mark	Page	Revision number
●	00-1	⑤		13-1	③		21-16	②	●	23-18	⑤		31-6	
	00-2	③		13-2	①		21-17	②	●	23-19	③		31-7	
●	00-2-1	⑤		13-2-1	③		21-18		●	23-20	⑤			
	00-2-2	④		13-3	①		21-19		●	23-21	⑤		33-1	④
	00-3			13-4	①		21-20	②	●	23-22	⑤		33-2	①
	00-4			13-5	①		21-21		●	23-23	⑤		33-3	①
	00-5			13-6	①		21-22		●	23-24	⑤		33-4	④
	00-6			13-7	①		21-23	③	○	23-24-1	⑤		33-5	④
	00-7			13-8	①		21-24		○	23-24-2	⑤		33-6	④
	00-8			13-9	①		21-25			23-25	①		33-7	④
	00-9			13-10	①		21-26			23-26	①		33-8	④
	00-10			13-11	①		21-27			23-27	①		33-9	④
				13-12	①		21-28	③		23-28	①		33-10	④
	11-1			13-13	①		21-29	③		23-29	①			
	11-2			13-14	①		21-30	③		23-30	①		34-1	
	11-3			13-15	①		21-31	③		23-31	①		34-2	
	11-4			13-16	①		21-32	③		23-32	①		34-3	
	11-5			13-17	①		21-33	②		23-33	①		34-4	
	11-6			13-18	①		21-34			23-34	①		34-5	
	11-7	③		13-19	①		21-35			23-35	①		34-6	
	11-8	③		13-20	①		21-36			23-36	①		34-7	
	11-9	③		13-21	①					23-37	①			
	11-10			13-22	③		23-1	①		23-38	①		61-1	③
	11-11						23-2	①		23-39	①		61-2	
	11-12			21-1			23-3	①		23-40	①		61-3	
	11-13			21-2	②		23-4	①		23-41	①		61-4	
	11-14			21-3			23-5	①		23-42	①		61-6	
				21-4	②		23-6	①		23-43	①		61-7	②
	12-1	③		21-5		●	23-7	⑤		23-44	③		61-7-1	②
	12-2	①		21-6		●	23-8	⑤					61-7-2	②
	12-3	①		21-7		●	23-9	⑤		24-1			61-8	②
	12-4	①		21-8		●	23-10	⑤		24-2			61-8-2	②
	12-5	①		21-9		●	23-11	⑤		24-3			61-9	②
	12-6	①		21-10		●	23-12	⑤		24-4	②		61-9-1	②
	12-7	①		21-11		●	23-13	⑤		24-5			61-9-2	②
	12-8	①		21-12		●	23-14	⑤					61-10	②
	12-9	④		21-13		●	23-15	⑤					61-12	
	12-10	③		21-14		●	23-16	⑤		31-1			61-13	②
	12-11	③		21-15		●	23-17	⑤		31-2			61-14	
										31-3			61-15	
										31-4			61-16	
										31-5			61-17	

MidWestTech | Komatsu PC60-5, PC60L-5, PC60U-5 Excavator Service Manual | Pub... Order the manual at mid-west-tech.com >

Mark	Page	Revision number	Mark	Page	Revision number	Mark	Page	Revision number	Mark	Page	Revision number	Mark	Page	Revision number
	61-18			61-74	②		62-41	①		62-94	①		63-42	①
	61-20			61-75	②		62-42	①		62-95	①		63-43	①
	61-21			61-76			62-43	①		62-96	①		63-44	①
	61-22						62-44	①		62-97	①			
	61-23	①		62-1	①		62-45	①		62-98	①		64-1	
	61-24	①		62-2	①		62-46	①		62-99	①		64-3	
	61-25			62-3	①		62-47	①					64-4	
	61-26			62-4	①		62-48	①		63-1	①		64-5	
	61-27	①		62-5	①		62-49	①		63-2	①		64-6	
	61-28	①		62-6	①		62-51	①		63-3	①		64-7	
	61-29	①		62-7	①		62-52	①		63-4	①		64-8	
	61-30	①		62-8	①		62-53	①		63-5	①		64-9	
	61-31	①		62-8-1	①		62-54	①		63-5-1	①		64-10	
	61-33	①		62-8-2	①		62-55	①		63-5-2	①		64-11	
	61-34	①		62-8-3	①		62-56	①		63-6	①		64-12	
	61-35	①		62-8-4	①		62-57	①		63-7	①		64-13	
	61-37	①		62-8-5	①		62-58	①		63-8	①		64-14	
	61-38	①		62-8-6	①		62-59	①		63-9	①		64-15	
	61-39	①		62-8-7	①		62-60	①		63-10	①			
	61-40	①		62-8-8	①		62-61	①		63-11	①		73-1	①
	61-41	①		62-9	①		62-62	①		63-12	①		73-2	①
	61-42	①		62-10	①		62-63	①		63-13	①		73-3	①
	61-43	①		62-11	①		62-64	①		63-14	①		73-4	①
	61-44	①		62-12	①		62-65	①		63-15	①		73-5	①
	61-45	①		62-13	①		62-66	①		63-16	①		73-6	①
	61-46	①		62-14	①		62-67	①		63-17	①			
	61-47	①		62-15	①		62-68	①		63-18	①		81-1	
	61-48	①		62-15-1	①		62-69	①		63-19	①		81-2	①
	61-49	①		62-15-2	①		62-70	①		63-20	①		81-3	②
	61-50	①		62-15-3	①		62-71	①		63-20-1	①		81-4	②
	61-51	①		62-16	①		62-72	①		63-20-2	①		81-5	③
	61-52	①		62-17	①		62-73	①		63-20-3	①			
	61-53			62-18	①		62-74	①		63-21	①		82-1	③
	61-54	②		62-19	①		62-75	①		63-22	①		82-2	③
	61-55			62-20	①		62-76	①		63-23	①		82-3	③
	61-56	②		62-21	①		62-77	①		63-24	①		82-4	③
	61-57			62-22	①		62-78	①		63-25	①		82-5	③
	61-58			62-23	①		62-79	①		63-26	①		82-6	③
	61-59			62-24	①		62-80	①		63-27	①			
	61-60			62-25	①		62-81	①		63-28	①			
	61-61			62-26	①		62-82	①		63-29	①			
	61-62			62-28	①		62-84	①		63-30	①			
	61-63			62-29	①		62-85	①		63-31	①			
	61-64			62-30	①		62-86	①		63-32	①			
	61-65			62-31	①		62-87	①		63-33	①			
	61-66			62-33	①		62-88	①		63-34	①			
	61-67			62-34	①		62-89	①		63-35	①			
	61-68	②		62-35	①		62-90	①		63-36	①			
	61-69	②		62-36	①		62-91	①		63-37	①			
	61-70	②		62-37	①		62-92	①		63-38	①			
	61-71	②		62-39	①		62-93	①		63-39	①			
	61-72	②								63-40	①			
	61-73	②								63-41	①			

MidWestTech | Komatsu PC60-5, PC60L-5, PC60U-5 Excavator Service Manual | Pub... Order the manual at mid-west-tech.com >



MidWestTech | Komatsu PC60-5, PC60L-5, PC60U-5 Excavator Service Manual | Publication SEBM02010505

Order the manual at mid-west-tech.com >