SEBM0383B01

SHOP MANUAL

W120-2

WHEEL LOADER

MACHINE MODEL
W120-2

SERIAL NO.
11001 AND UP

KOMATSU®

MidWestTech | Komatsu W120-2 Wheel Loader Service Manual | Publication SEBM0383B01

Order the manual at mid-west-tech.com >

CONTENTS

No. of page

GENERAL 01-1

POWER TRAIN

21 STRUCTURE AND FUNCTION 21-1
22 TESTING AND ADJUSTING 22-1
23 DISASSEMBLY AND ASSEMBLY 23-1
24 MAINTENANCE STANDARD 24-1

STEERING SYSTEM

41 STRUCTURE AND FUNCTION 41-1
42 TESTING AND ADJUSTING 42-1
43 DISASSEMBLY AND ASSEMBLY 43-1
44 MAINTENANCE STANDARD 44-1

AIR SYSTEM

51 STRUCTURE AND FUNCTION 51-1
52 TESTING AND ADJUSTING 52-1
53 DISASSEMBLY AND ASSEMBLY 53-1
54 MAINTENANCE STANDARD 54-1

HYDRAULIC SYSTEM

61 STRUCURE AND FUNCTION 61-1
62 TESTING AND ADJUSTING 62-1
63 DISASSEMBLY AND ASSEMBLY 63-1
64 MAINTENANCE STANDARD 64-1

WORK EQUIPMENT


71 STRUCTURE AND FUNCTION 71-1
72 TESTING AND ADJUSTING 72-1
73 DISASSEMBLY AND ASSEMBLY 73-1
74 MAINTENANCE STANDARD 74-1

OTHERS

91 ELECTRICAL SYSTEM 91-1

MidWestTech | Komatsu W120-2 Wheel Loader Service Manual | Publication SEBM03... Order the manual at mid-west-tech.com >

HYDRAULIC OIL CIRCUIT



MidWestTech | Komatsu W120-2 Wheel Loader Service Manual | Publication SEBM0383B01 Order the manual at mid-west-tech.com >