SEBM04160105

SHOP MANUAL

KOMATSU®

WA100-1

MACHINE MODEL SERIAL No.

WA100-1 10001 and up

MidWestTech | Komatsu WA100-1 Wheel Loader Service Manual | Publication SEBM04160105

Order the manual at mid-west-tech.com >

CONTENTS

No. of page

10 ENGINE

11 STRUCTURE AND FUNCTION 11-1
12 TESTING AND ADJUSTING 12-1
13 DISASSEMBLY AND ASSEMBLY 13-1

20 POWER TRAIN

21 STRUCTURE AND FUNCTION 21-1
22 TESTING AND ADJUSTING 22-1
23 DISASSEMBLY AND ASSEMBLY 23-1
24 MAINTENANCE STANDARD 24-1

40 STEERING SYSTEM

41 STRUCTURE AND FUNCTION 41-1
42 TESTING AND ADJUSTING 42-1
43 DISASSEMBLY AND ASSEMBLY 43-1
44 MAINTENANCE STANDARD 44-1

50 BRAKE SYSTEM

51 STRUCTURE AND FUNCTION 51-1
52 TESTING AND ADJUSTING 52-1
53 DISASSEMBLY AND ASSEMBLY 53-1
54 MAINTENANCE STANDARD 54-1

60 WORK EQUIPMENT

61 STRUCTURE AND FUNCTION 61-1
62 TESTING AND ADJUSTING 62-1
63 DISASSEMBLY AND ASSEMBLY 63-1
64 MAINTENANCE STANDARD 64-1

80 ELECTRIC AND ELECTRONIC SYSTEM

81 STRUCTURE AND FUNCTION 81-1
82 TESTING AND ADJUSTING 82-1
83 DISASSEMBLY AND ASSEMBLY 83-1

90 OTHERS

91 STRUCTURE AND FUNCTION 91-1
93 DISASSEMBLY AND ASSEMBLY 93-1
97 GEAR PUMP 97-1

MidWestTech | Komatsu WA100-1 Wheel Loader Service Manual | Publication SEBM0... Order the manual at mid-west-tech.com >

The affected pages are indicated by the use of the following marks. It is requested that necessary actions must be taken to these pages according to the list below.

Mark	Indication	Action required
○	Page to be newly added	Add
●	Page to be replaced	Replace
( )	Page to be deleted	Discard


Pages having no marks are not revised at this time.

LIST OF REVISED PAGES

Mark	Page	Revision number	Mark	Page	Revision number	Mark	Page	Revision number	Mark	Page	Revision number	Mark	Page	Revision number
●	00- 1	5		11- 5	4	●	13-25	5		21-25	2		22-19	1
	00- 2	4		11- 6	4	●	13-26	5		21-26			22-20	1
●	00- 2-1	5		12- 1	1		13-27	2		21-27			22-21	1
●	00- 2-2	5		12- 2	4	●	13-28	5		21-28			22-22	1
●	00- 2-3	5		12- 3	1	●	13-29	5		21-29			22-23	1
	00- 3			12- 4	2	●	13-30	5		21-30			22-24	1
	00- 4			12- 5	2	●	13-31	5		21-31			23- 1	2
	00- 5			12- 6	2		13-32	2		21-32			23- 2	2
	00- 6			12- 7	1		13-33	2		21-33			23- 4	2
	00- 7			12- 8	2		13-34	2		21-34		●	23- 5	5
	00- 8			12- 9	1		13-35	2		21-35			23- 6	2
	00- 9			12-10	1		13-36	2		21-36		●	23- 7	5
	00-10			12-11	4	●	13-37	5		21-37	2	●	23- 8	5
	00-11			12-12	4	●	13-38	5		21-38			23- 9	2
	00-12			12-13	4		13-39	2		21-39		●	23-10	5
	00-13			12-14	4	●	13-40	5		21-40	4		23-11	2
	00-14			13- 1	2		13-41	2		21-41	4		23-12	2
	00-15			13- 2	2		21- 1	4		21-42			23-14	2
	00-16			13- 3	2		21- 2			21-43			23-15	2
	00-17			13- 4	2		21- 3			21-44	4	●	23-16	5
	00-18			13- 5	2		21- 4	4		21-46		●	23-17	5
	00-19			13- 6	2		21- 5	4		21-47			23-18	2
	00-20		●	13- 7	5		21- 6	4		21-48		●	23-19	5
	00-21		●	13- 8	5		21- 7			22- 1	1	●	23-20	5
	00-22		●	13- 9	5		21- 8			22- 2	4	●	23-21	5
	00-23			13- 9-1	5		21- 9	4		22- 3	3		23-22	2
	00-24			13-10	2		21-10	4		22- 4	3		23-23	2
	00-25			13-11	2		21-11	2		22- 5	1		23-24	2
	00-26		●	13-12	5		21-12			22- 6	3		23-25	2
	00-27			13-13	2		21-14			22- 7	1		23-26	2
	00-28			13-14	2		21-15	4		22- 8	3		23-27	2
	00-29			13-16	2		21-16	4		22- 9	3		23-28	2
	00-30			13-17	2		21-17	4		22-10	1		23-29	2
	00-31			13-18	2		21-18	4		22-11	1	●	23-30	5
	00-33	4		13-19	2		21-18-1	4		22-12	1		23-31	2
	00-34	4		13-20	2		21-19			22-13	1		23-32	2
	11- 1	4	●	13-21	5		21-20			22-14	1		23-33	2
	11- 2		●	13-22	5		21-21			22-15	1		23-34	2
	11- 3	4	●	13-23	5		21-22			22-16	1	●	23-35	5
	11- 4	4	●	13-24	5		21-24	4		22-18	1	●	23-36	5

MidWestTech | Komatsu WA100-1 Wheel Loader Service Manual | Publication SEBM0... Order the manual at mid-west-tech.com >

ELECTRICAL WIRING DIAGRAM CIRCUIT SERIAL No. 10001 – 19999



416F106

MidWestTech | Komatsu WA100-1 Wheel Loader Service Manual | Publication SEBM04160105

Order the manual at mid-west-tech.com >