SEBMG5250108

SHOP MANUAL

KOMATSU®

GD510, GD520 SERIES

MACHINE MODEL	SERIAL No.	COMPONENT TYPE
GD521A-1	**10001 and up**	**A**
GD522A-1	**20001 and up**	**B**
GD523A-1	**30001 and up**	**C**
GD525A-1	**50001 and up**	**D**
GD511A-1	**10001 and up**	**E**
GD513A-1	**30001 and up**	**F**
GD521R-1	**10001 and up**	**G**
GD523R-1	**30001 and up**	**H**
GD511R-1	**10001 and up**	**J**
GD513R-1	**30001 and up**	**K**
GD510R-1	**15001 and up**	**L**
GD515A-1	**50001 and up**	**M**
GD525A-1C	**60001 and up**	**N**
GD525A-1A	**50001 and up**	**See table of applicable components.**
GD525A-1B	**55001 and up**	

(All component and parts for the GD510R-1, with the exceptions of the transmission and main clutch, are interchangeable with those of the GD511R-1.)

MidWestTech | Komatsu GD510, GD520 Series Motor Grader Service Manual | Publication SEBMG5250108 Order the manual at mid-west-tech.com >

SHOP MANUAL

KOMATSU

GD510, GD520 SERIES

MACHINE MODEL	SERIAL No.	COMPONENT TYPE
GD521A-1	10001 and up	A
GD522A-1	20001 and up	B
GD523A-1	30001 and up	C
GD525A-1	50001 and up	D
GD511A-1	10001 and up	E
GD513A-1	30001 and up	F
GD521R-1	10001 and up	G
GD523R-1	30001 and up	H
GD511R-1	10001 and up	J
GD513R-1	30001 and up	K
GD510R-1	15001 and up	L
GD515A-1	50001 and up	M
GD525A-1C	60001 and up	N
GD525A-1A	50001 and up	See table of applicable components.
GD525A-1B	55001 and up	

(All component and parts for the GD510R-1, with the exceptions of the transmission and main clutch, are interchangeable with those of the GD511R-1.)

© 2016 KOMATSU
All Rights Reserved
Printed in Japan 12-16 (01)

MidWestTech | Komatsu GD510, GD520 Series Motor Grader Service Manual | Public... Order the manual at mid-west-tech.com >

CONTENTS

No. of page

10 ENGINE

12 TESTING AND ADJUSTING 12-1
13 DISASSEMBLY AND ASSEMBLY 13-1

20 POWER TRAIN

21 STRUCTURE AND FUNCTION 21-1
22 TESTING AND ADJUSTING 22-1
23 DISASSEMBLY AND ASSEMBLY 23-1
24 MAINTENANCE STANDARD 24-1

40 STEERING SYSTEM

41 STRUCTURE AND FUNCTION 41-1
42 TESTING AND ADJUSTING 42-1
43 DISASSEMBLY AND ASSEMBLY 43-1
44 MAINTENANCE STANDARD 44-1

50 BRAKE SYSTEM

51 STRUCTURE AND FUNCTION 51-1
52 TESTING AND ADJUSTING 52-1
53 DISASSEMBLY AND ASSEMBLY 53-1
54 MAINTENANCE STANDARD 54-1

60 HYDRAULIC SYSTEM

61 STRUCTURE AND FUNCTION 61-1
63 DISASSEMBLY AND ASSEMBLY 63-1
64 MAINTENANCE STANDARD 64-1

70 WORK EQUIPMENT


71 STRUCTURE AND FUNCTION 71-1
72 TESTING AND ADJUSTING 72-1
73 DISASSEMBLY AND ASSEMBLY 73-1
74 MAINTENANCE STANDARD 74-1

80 ELECTRIC AND ELECTRONIC SYSTEM

81 STRUCTURE AND FUNCTION 81-1
82 TESTING AND ADJUSTING 82-1

MidWestTech | Komatsu GD510, GD520 Series Motor Grader Service Manual | Public... Order the manual at mid-west-tech.com >

M, N Type



MidWestTech | Komatsu GD510, GD520 Series Motor Grader Service Manual | Publication SEBMG5250108

Order the manual at mid-west-tech.com >