SEBMU1340106

SHOP MANUAL

KOMATSU®

D58E-1, 1A, 1B

D58P-1, 1B

MACHINE MODEL	SERIAL NUMBER
D58E-1	**80888 and up**
D58E-1A	**80888 and up**
D58E-1B	**81285 and up**
D58P-1	**80588 and up**
D58P-1B	**81261 and up**

- This shop manual may contain attachments and optional equipment that are not available in your area. Please consult your local Komatsu distributor for those items you may require. Materials and specifications are subject to change without notice.

- D58-1 mounts the 6D125-1 and 6D125-2 engines.
  For details of the engine, see the 6D125-1 Series and 125-2 Series Engine Shop Manual.

MidWestTech | Komatsu D58E-1, D58E-1A, D58E-1B, D58P-1, D58P-1B Crawler Dozer Service Manual | Publication SEBMU1340106
Order the manual at mid-west-tech.com >

CONTENTS

No. of page

01 GENERAL 01-1

10 ENGINE
11 STRUCTURE AND FUNCTION 11-1
12 TESTING AND ADJUSTING 12-1
13 DISASSEMBLY AND ASSEMBLY 13-1

20 POWER TRAIN
21 STRUCTURE AND FUNCTION 21-1
22 TESTING AND ADJUSTING 22-1
23 DISASSEMBLY AND ASSEMBLY 23-1
24 MAINTENANCE STANDARD 24-1

30 UNDERCARRIAGE
31 STRUCTURE AND FUNCTION 31-1
33 DISASSEMBLY AND ASSEMBLY 33-1
34 MAINTENANCE STANDARD 34-1

60 HYDRAULIC SYSTEM
61 STRUCTURE AND FUNCTION 61-1
62 TESTING AND ADJUSTING 62-1
63 DISASSEMBLY AND ASSEMBLY 63-1
64 MAINTENANCE STANDARD 64-1

70 WORK EQUIPMENT
71 STRUCTURE AND FUNCTION 71-1
73 DISASSEMBLY AND ASSEMBLY 73-1
74 MAINTENANCE STANDARD 74-1

80 ELECTRICAL SYSTEM
81 STRUCTURE AND FUNCTION 81-1
82 TESTING AND ADJUSTING 82-1

MidWestTech | Komatsu D58E-1, D58E-1A, D58E-1B, D58P-1, D58P-1B Crawler Doze... Order the manual at mid-west-tech.com >

The affected pages are indicated by the use of the following marks. It is requested that necessary actions must be taken to these pages according to the list below.

Mark	Indication	Action required
○	Page to be newly added	Add
●	Page to be replaced	Replace
( )	Page to be deleted	Discard

Pages having no marks are not revised at this time.

LIST OF REVISED PAGES

Mark	Pages	Revision number
●	00- 1	⑥
	00- 2	⑤
●	00- 2-1	⑥
●	00- 2-2	⑤
●	00- 2-3	⑥
●	00- 3	
●	00- 4	
●	00- 5	
●	00- 6	
●	00- 7	
●	00- 8	
●	00- 9	
●	00-10	
●	00-11	
●	00-12	
●	00-13	
●	00-14	
●	00-15	
●	00-16	
●	00-17	
□	00-18	
□	00-19	
	01- 1	④
	01- 2	④
□	01- 2-1	⑥
□	01- 2-2	⑥
●	01- 3	⑥
	01- 4	④
	01- 5	④
	01- 6	④
	01- 7	④
	01- 8	④
	01- 9	④
	01-10	④
	01-11	④
	01-12	④
	01-13	④
	01-14	④
	11- 1	
	11- 2	
	11- 3	
	11- 4	
	11- 5	
	11- 6	
	12- 1	⑤
	12- 2	⑤
	12- 2-1	⑤
	12- 3	⑤
	12- 4	⑤
	12- 5	⑤
	12- 6	⑤
	12- 7	⑤
	12- 8	⑤
	12- 9	⑤
	12-10	⑤
	12-11	⑤
	12-12	⑥
	12-13	⑤
	12-14	⑥
	12-15	⑤
	12-16	⑤
	12-17	⑤
	12-18	⑥
	12-19	⑤
	12-20	⑥
	12-21	⑤
	12-22	⑤
	12-23	⑤
	12-24	⑤
	12-25	⑤
	12-26	⑤
	12-27	⑤
	12-28	⑤
	12-29	⑤
	12-30	⑤
	12-31	⑤
	12-32	⑤
	12-33	⑤
	12-34	⑤
	12-35	⑤
	12-36	⑤
	12-37	⑤
	13- 1	⑤
	13- 2	⑤
	13- 3	⑤
	13- 3-1	⑤
	13- 3-2	⑤
	13- 4	⑤
	13- 5	⑥
	13- 6	⑤
	13- 7	⑤
	13- 7-1	⑤
	13- 7-2	⑤
	13- 7-3	⑤
	13- 7-4	⑤
	13- 7-5	⑤
	13- 8	⑥
	13- 9	①
	13-10	①
	13-11	⑤
	13-12	①
	13-13	①
	13-14	①
	13-14-1	⑤
	13-14-2	⑤
	13-14-3	⑤
	13-14-4	⑤
	13-14-5	⑤
	13-14-6	⑤
	13-14-7	⑤
	13-14-8	⑤
	13-14-9	⑤
	13-14-10	⑤
	13-14-11	⑤
	13-15	①
	13-16	①
	13-17	①
	13-18	①
	13-19	⑤
	13-20	①
	13-21	⑤
	13-22	①
	13-22-1	⑤
	13-22-2	⑤
	13-23	⑤
	13-24	①
	13-25	⑤
	13-26	①
	13-27	⑤
	13-28	⑤
●	21- 1	⑥
	21- 2	
	21- 2-1	⑤
	21- 3	
	21- 4	
	21- 5	③
	21- 6	
	21- 7	
	21- 8	
	21- 9	③
	21-10	③
	21-11	②
	21-11-2	③
	21-12	③
	21-13	③
	21-14	
	21-15	
	21-16	
	21-17	
	21-18	
	21-19	
	21-20	
	21-21	
	21-22	
□	21-22-1	⑥
	21-23	④
	21-23-1	④
	21-24	④
	21-25	③
□	21-25-1	⑥
○	21-25-2	⑥
	21-26	
	21-27	③
	21-27-1	③
	21-27-2	③
○	21-27-3	⑥
	21-28	②
	21-29	③
	21-30	
	21-31	
	21-32	
	21-33	
	21-34	
○	21-35	⑥
	21-36	①
	21-37	
□	21-37-1	⑤
○	21-37-2	⑤
	21-38	
	21-39	
	21-40	
	21-41	
	21-42	
	21-43	
	21-44	
○	21-45	⑤
○	21-45-1	⑤
○	21-45-2	⑤
○	21-45-3	⑤
○	21-45-4	⑤
○	21-45-5	⑤
○	21-45-6	⑤
	21-46	①
	21-47	①
	21-48	①
	21-49	
	21-50	
	21-51	
	21-52	
	21-53	

MidWestTech | Komatsu D58E-1, D58E-1A, D58E-1B, D58P-1, D58P-1B Crawler Doze... Order the manual at mid-west-tech.com >


Mark	Pages	Revision number
	21-54	
	21-55	④
	21-56	④
	21-56-1	④
	21-57	③
	21-58	
	21-59	
	21-60	
	21-61	
●	22- 1	⑤
	22- 2	⑤
	22- 3	⑤
	22- 3-1	⑤
	22- 3-2	⑤
○	22- 3-3	⑥
●	22- 4	⑥
	22- 5	
	22- 6	
	22- 7	①
	22- 8	
	22- 9	④
○	22- 9-1	⑥
○	22- 9-2	⑤
	22-10	⑤
	22-11	
	22-12	
	22-13	
	22-14	
	22-15	
	22-16	
	22-17	
	22-18	
	22-19	
	22-20	
	22-21	
	23- 1	①
	23- 2	①
	23- 3	①
	23- 4	①
	23- 5	①
	23- 6	①
	23- 7	①
	23- 8	①
	23- 9	①
	23-10	①
	23-11	①
	23-12	①
	23-13	①
	23-14	①
	23-15	①
	23-16	①
	23-17	①
	23-18	①
	23-19	①
	23-20	①
	23-21	①
	23-22	①
	23-23	①
	23-24	①
	23-25	①
	23-26	①
	23-27	①
	23-28	①
	23-29	①
	23-30	①
	23-31	①
	23-32	①
	23-33	①
	23-34	①
	23-35	①
	23-36	①
	23-37	①
	23-38	③
	23-39	①
	23-40	①
	23-41	①
	23-42	①
	23-43	①
	23-44	①
	23-45	①
	23-46	①
	23-47	①
	23-48	①
	23-49	①
	23-50	①
	23-51	①
	23-52	①
	23-53	①
	23-54	①
	23-55	①
	23-56	①
	23-58	①
	23-59	①
	23-60	②
	23-61	③
	23-62	①
	23-63	①
	23-64	①
	23-65	①
	23-66	①
	23-67	①
	23-68	①
	23-69	①
	23-70	①
	23-71	①
	23-72	①
	23-73	
	23-74	①
	23-75	①
	23-76	③
	23- 77	①
	23- 78	①
	23- 79	①
	23- 80	①
	23- 81	①
	23- 82	①
	23- 83	①
	23- 84	①
	23- 85	①
	23- 86	①
	23- 87	①
	23- 88	①
	23- 89	①
	23- 90	①
	23- 91	①
	23- 92	①
	23- 93	①
	23- 94	①
	23- 95	①
	23- 96	①
	23- 98	①
	23- 99	①
	23-100	①
	23-101	①
	23-102	①
	23-103	①
	23-104	①
	23-105	①
	23-106	
	23-107	①
	23-108	①
	23-109	①
	23-110	①
	23-111	①
	23-112	①
	23-113	①
	23-114	①
	23-115	①
	24- 1	②
	24- 2	
	24- 4	③
	24- 5	③
	24- 5-1	③
	24- 5-2	③
	24- 6	③
	24- 7	③
	24- 8	③
	24- 9	
	24- 9-1	③
	24- 9-2	③
	24- 9-3	③
	24- 9-4	③
○	24- 9-5	⑥
○	24- 9-6	⑥
	24- 10	
	24-11	
	24-12	
	24-13	
	24-14	
	24-15	
○	24-15-1	⑥
○	24-15-2	⑥
●	24-16	⑥
	24-17	
	24-18	①
	24-19	①
	24-20	②
	24-21	②
	24-22	
	31- 1	
	31- 2	②
	31- 3	
	31- 4	
	31- 5	
	31- 5-1	⑥
	31- 6	⑤
	31- 7	
	31- 8	
	31- 9	
	31-10	
	31-11	
	31-12	
	33- 1	⑥
	33- 2	①
	33- 3	①
	33- 4	①
	33- 5	①
	33- 6	①
	33- 7	①
	33- 8	①
	33- 9	①
	33-10	①
	33-11	①
	33-12	①
	33-13	①
	33-14	
	33-15	①
	33-15-1	⑤
	33-15-2	⑤
	33-15-3	⑤
	33-15-4	⑤
	33-15-5	⑤
	33-15-6	⑤
	33-16	①
	33-18	①
	33-19	①
	33-20	①
	33-21	①
	33-22	①
	34- 1	
	34- 2	②
	34- 3	
●	34- 4	⑤
●	34- 5	⑤
●	34- 5-1	⑥
●	34- 5-2	⑤
	34- 6	
	34- 7	
	34- 8	
	34- 9	
	34-10	
	34-11	
	34-12	
	34-13	①
	34-14	
	34-15	①
	34-16	
	34-17	
	34-18	
	34-19	
	34-20	
●	61- 1	⑥
	61- 2	
	61- 2-1	④
	61- 3	
	61- 4	
	61- 5	
	61- 6	②
	61- 7	
	61- 8	②
	61- 9	
	61- 9-1	②
	61- 9-2	②
○	61- 9-3	⑥
○	61- 9-4	⑥
	61-10	②
	61-11	
	61-11-1	②
○	61-11-2	⑤
○	61-11-3	⑥
○	61-11-4	⑥
○	61-11-5	⑥
○	61-11-6	⑥
○	61-11-7	⑥
○	61-11-8	⑥
	61-12	②
	61-12-1	②
	61-12-2	②
○	61-12-3	⑥
	61-13	
	61-14	
	61-15	
	61-15-1	②
	61-15-2	②
	61-15-3	②

MidWestTech | Komatsu D58E-1, D58E-1A, D58E-1B, D58P-1, D58P-1B Crawler Doze... Order the manual at mid-west-tech.com >

D58E-1B

- **Power angle and power tilt dozer (Joystick control specification)**

Unit: mm



MidWestTech | Komatsu D58E-1, D58E-1A, D58E-1B, D58P-1, D58P-1B Crawler Doze... Order the manual at mid-west-tech.com >

METHOD OF USING TROUBLESHOOTING CHARTS

This troubleshooting chart is divided into three sections: **questions, check items, and troubleshooting**. The questions and check items are used to pinpoint high probability causes that can be located from the failure symptoms or simple inspection without using troubleshooting tools.

Next, troubleshooting tools or direct inspection are used to check the high probability causes to make final confirmation.

[Questions]

Sections Ⓐ + Ⓑ in the chart on the right correspond to the items where answers can be obtained from the user. The items in Ⓑ are items that can be obtained from the user, depending on the user's level.


[Check items]

The serviceman carries out simple inspection to narrow down the causes. The items under Ⓒ in the chart on the right correspond to this.

The serviceman narrows down the causes from information Ⓐ that he has obtained from the user and the results of Ⓒ that he has obtained from his own inspection.


[Troubleshooting]

Troubleshooting is carried out in the order of probability, starting with the causes that have been marked as having the highest probability from information gained from **[Questions]** and **[Check items]**.



MidWestTech | Komatsu D58E-1, D58E-1A, D58E-1B, D58P-1, D58P-1B Crawler Doze... Order the manual at mid-west-tech.com >

REGULATION OF EC INCLUSION



MidWestTech | Komatsu D58E-1, D58E-1A, D58E-1B, D58P-1, D58P-1B Crawler Dozer Service Manual | Publication SEBMU1340106
Order the manual at mid-west-tech.com >