SEBMU4240106

SHOP MANUAL

KOMATSU®

WA420-1

MACHINE MODEL | SERIAL No.

WA420-1 | **10001 and up**

- This shop manual may contain attachments and optional equipment that are not available in your area. Please consult your local Komatsu distributor for those items you may require. Materials and specifications are subject to change without notice.

- WA420-1 mount the SA6D110-1 engine.
  For details of the engine, see the 110 Series Engine Shop Manual.

MidWestTech | Komatsu WA420-1 Wheel Loader Service Manual | Publication SEBMU4240106
Order the manual at mid-west-tech.com >

CONTENTS

No. of page

10 ENGINE

12 TESTING AND ADJUSTING 12-1
13 DISASSEMBLY AND ASSEMBLY 13-1

20 POWER TRAIN

21 STRUCTURE AND FUNCTION 21-1
22 TESTING AND ADJUSTING 22-1
23 DISASSEMBLY AND ASSEMBLY 23-1
24 MAINTENANCE STANDARD 24-1

40 STEERING SYSTEM

41 STRUCTURE AND FUNCTION 41-1
42 TESTING AND ADJUSTING 42-1
43 DISASSEMBLY AND ASSEMBLY 43-1
44 MAINTENANCE STANDARD 44-1

50 BRAKE AND AIR SYSTEM

51 STRUCTURE AND FUNCTION 51-1
52 TESTING AND ADJUSTING 52-1
53 DISASSEMBLY AND ASSEMBLY 53-1
54 MAINTENANCE STANDARD 54-1

60 WORK EQUIPMENT SYSTEM

61 STRUCTURE AND FUNCTION 61-1
62 TESTING AND ADJUSTING 62-1
63 DISASSEMBLY AND ASSEMBLY 63-1
64 MAINTENANCE STANDARD 64-1

80 ELECTRIC AND ELECTRONIC SYSTEM

81 STRUCTURE AND FUNCTION 81-1
82 TESTING AND ADJUSTING 82-1
83 DISASSEMBLY AND ASSEMBLY 83-1

90 OTHERS

93 DISASSEMBLY AND ASSEMBLY 93-1
97 GEAR PUMP 97-1

MidWestTech | Komatsu WA420-1 Wheel Loader Service Manual | Publication SEBM... Order the manual at mid-west-tech.com >