Hydrostatic Transmission

Service Manual

SM43

CASE IH AGRICULTURE

MidWestTech | Case 454, 474, 574 Tractor Hydrostatic Transmission Service Manual | Publication SM43

Order the manual at mid-west-tech.com >


GROUP 1

GENERAL

	PAGE NUMBERS
GENERAL	1
SERVICE	1
SERVICE PARTS	1
ADJUSTMENTS	1
ILLUSTRATION REFERENCES	1
INSPECTION AND REPAIR	1
LUBRICATION	3
METRIC CONVERSION	3
BOLT IDENTIFICATION	3
STANDARD TORQUE DATA FOR NUTS AND BOLTS	4
STANDARD TORQUE DATA FOR TUBE FITTINGS	5
PRINCIPLES OF HYDROSTATICS	6
PRINCIPLES OF OPERATION (HAND CONTROLLED)	12
PRINCIPLES OF OPERATION (FOOT CONTROLLED)	15
SPECIFICATIONS	17
SERVICE TOOLS	19

MidWestTech | Case 454, 474, 574 Tractor Hydrostatic Transmission Service Manual | Pub... Order the manual at mid-west-tech.com >

FORWARD (Decelerating) (Hand Controlled) (Servos at rest, Foot-N-Inch valve open)



Order the manual at mid-west-tech.com >