SMEW380000

SHOP MANUAL



WA380-3

WHEEL LOADER

SERIAL NUMBERS **WA380-10001** And up

KOMATSU®


⚠ WARNING


Unsafe use of this machine may cause serious injury or death. Operators and maintenance personnel must read this manual before operating or maintaining this machine. This manual should be kept near the machine for reference and periodically reviewed by all personnel who will come into contact with it.


KCSM


MidWestTech | Komatsu WA380-3 Wheel Loader Service Manual | Publication SMEW380000


Order the manual at mid-west-tech.com >











SDW01218

1. Transmission case
2. Transmission control valve
3. Accumulator valve
4. Oil filter
5. Torque converter charging pump (SAL (2) 45 + 20)
6. Transmission oil filler
7. REVERSE clutch
8. FORWARD clutch
9. Input shaft
10. Torque converter
11. 3rd clutch
12. 4th clutch
13. Rear coupling
14. Output shaft
15. Parking brake
16. Front coupling
17. 2nd, 4th shaft
18. 2nd clutch
19. 1st, 3rd shaft
20. 1st clutch
21. REVERSE idler gear
22. Strainer

U42303

MidWestTech | Komatsu WA380-3 Wheel Loader Service Manual | Publication SMEW380000 Order the manual at mid-west-tech.com >