
SHOP MANUAL



SMEW4700K0

AVANCE

LOADER CUSTOM

WA470-3

WHEEL LOADER


SERIAL NUMBERS WA470-3 20001 and up

KOMATSU®

MidWestTech | Komatsu Avance Max Custom WA470-3 Wheel Loader Service Manual | Publication SMEW4700K0

Order the manual at mid-west-tech.com >

BRAKE PIPING



1. Brake valve (right)
2. Hydraulic tank
3. Parking brake switch
4. Parking brake emergency cancel switch
5. Rear brake
6. Charge valve
7. Accumulator
8. Slack adjuster
9. Rear brake
10. PPC brake pump
11. Transmission control valve
12. Parking brake valve
13. Parking brake
14. Brake valve (left)
15. Front brake
16. Slack adjuster
17. Front brake

MidWestTech | Komatsu Avance Max Custom WA470-3 Wheel Loader Service Manual | Publication SMEW4700K0
Order the manual at mid-west-tech.com >