PART NO. TOJBF90-EN-00

HITACHI

Reliable solutions

Technical Manual
Operational Principle

ZX670LC-5G
Hydraulic Excavator

Service Manual consists of the following separate Part No.

Technical Manual (Operational Principle)	: Vol. No.TOJBF90-EN
Technical Manual (Troubleshooting)	: Vol. No.TTJBF90-EN
Workshop Manual	: Vol. No.WJBF90-EN

MidWestTech | Hitachi ZX670LC-5G Excavator Operational Principle Technical Service Manual | Publication TOJBF90-EN-00

Order the manual at mid-west-tech.com >

SECTION 1

GENERAL

CONTENTS

Group 1 Specifications

Specifications T1-1-1
Working Ranges T1-1-2

Group 2 Component Layout

Main Component T1-2-1
View A T1-2-2
Electrical System (Overview) T1-2-3
Electrical System (Rear Tray) T1-2-4
Electrical System (Switch Panel) T1-2-5
Electrical System (Cab Behind Side) T1-2-6
Isolation Switch (Optional) T1-2-7
Around Horn T1-2-8
Boom Upper Side T1-2-8
Around Oil Cooler T1-2-8
Auto Lubricating System T1-2-8
Engine T1-2-9
Pump Device T1-2-10
Control Valve T1-2-11
Check Valve/Accumulator T1-2-12
Signal Control Valve T1-2-12
4-Spool Solenoid Valve Unit T1-2-15
2-Spool Solenoid Valve Unit T1-2-15

Group 3 Component Specifications

Engine T1-3-1
Engine Accessories T1-3-5
Hydraulic Component T1-3-7
Electrical Component T1-3-11

MidWestTech | Hitachi ZX670LC-5G Excavator Operational Principle Technical Service... Order the manual at mid-west-tech.com >

Engine Accessories

RADIATOR ASSEMBLY	Type	Parallel Type
	Weight	400 kg (882 lb)

	Radiator	Intercooler
Capacity	20.8 L (5.5 US gal)	40 L (11 US gal)
Air-Tight Test Pressure	100 kPa (1.0 kgf/cm², 15 psi)	150 kPa (1.5 kgf/cm², 22 psi)
Cap Opening Pressure	49 kPa (0.5 kgf/cm², 7 psi)	–

	Oil Cooler
Capacity	25.5 L (6.7 US gal)
Air-Tight Test Pressure	1500 kPa (15 kgf/cm², 218 psi)
Cap Opening Pressure	–

MidWestTech | Hitachi ZX670LC-5G Excavator Operational Principle Technical Service... Order the manual at mid-west-tech.com >


Overheat Prevention Control


Purpose:
The overheat prevention control reduces the maximum flow rate and the driving torque of the pump when coolant temperature and hydraulic oil temperature increase to the specified value or more in order to reduce the engine load and prevent the overheating.
It maximizes the fan pump delivery flow rate and the fan speed at the same time.
Operation:

1. MC (13) receives the signal from coolant temperature sensor (20) through monitor controller (15) and CAN (17).
2. When engine coolant temperature is 99 °C or more, MC (13) calculates the target pump displacement angle including the signals from pump 1 and pump 2 delivery pressure sensors ((22), (23)). In addition, MC (13) compares the actual pump displacement angle detected by pump 1 and pump 2 control pressure sensors ((27), (25)) with the target pump displacement angle.
3. MC (13) drives pump 1 control solenoid valve (26) and pump 2 control solenoid valve (24) in order to align the actual pump displacement angle with the target pump displacement angle so that the pump driving torque is reduced by 7%.
4. In addition, MC (13) receives the signal from hydraulic oil temperature sensor (1).
5. When hydraulic oil temperature is 100 °C or more, MC (13) calculates the target pump displacement angle including the signals from pump 1 and pump 2 delivery pressure sensors ((23), (23)). In addition, MC (13) compares the actual pump displacement angle detected by pump 1 and pump 2 control pressure sensors ((27), (25)) with the target pump displacement angle.
6. MC (13) drives pump 1 control solenoid valve (26) and pump 2 control solenoid valve (24) to the difference of pump displacement angle between the actual angle and the target angle so that the pump displacement angle is reduced and the pump driving torque is reduced by 7%.
7. MC (13) calculates the fan speed according to each input signal on temperature at the same time.
8. MC (13) sends the highest output signal of the calculated fan speed to fan pump control solenoid valve (35) and maximizes the fan pump delivery flow rate.
9. Consequently, the fan speed is controlled to maximum.

Overheat control completed condition:

- Coolant temperature: 95 °C or less
- Hydraulic oil temperature: 95 °C or less





P - Pressure Q - Flow Rate

MidWestTech | Hitachi ZX670LC-5G Excavator Operational Principle Technical Service... Order the manual at mid-west-tech.com >

Hydraulic Circuit

Main Circuit

Pressure oil from pump 1 flows to each spool of travel (right), bucket, boom 1, and arm 2 at the 4-spool side of control valve.Pressure oil from pump 2 flows to each spool of swing, arm 1, boom 2, auxiliary, and travel (left) at the 5-spool side of control valve.


The parallel circuit is provided in each main circuit of pump 1 and pump 2, and makes the combined operation possible.
In addition, the flow combiner circuit is provided in both boom and arm circuits so that pressure oil from pump 1 and pump 2 are combined during a single operation.

The main relief valve (15) is provided in the main circuit (between the pump and the actuator). The main relief valve (15) prevents the pressure in the main circuit from exceeding the set pressure when the spool is operated (or when the control lever is operated).
The overload relief valves (6, 11, 19, 22 and 29) are provided in the actuator circuits (between the control valve and the actuator) of boom, arm, bucket, and auxiliary. The overload relief valve prevents surge pressure caused by external force in the actuator circuit does not exceed the set pressure when the spool is in neutral (with the control lever set in neutral).


In addition, boom overload relief valve (low pressure) (22) is provided in the boom lower circuit.Boom overload relief valve (low pressure) (22) decreases the relief set pressure in the boom lower circuit and reduces vibration of the machine during boom lower operation.

MidWestTech | Hitachi ZX670LC-5G Excavator Operational Principle Technical Service... Order the manual at mid-west-tech.com >

Front Attachment / Swing Pilot Valve




TPPP-03-04-007




TPPP-03-04-008

Travel Pilot Valve



TPPP-03-04-012




TPPP-03-04-013


P- Port P
T- Port T
a- Output Port

1- Cam
2- Pusher
3- Casing
4- Spring Guide
5- Balance Spring
6- Return Spring
7- Spool
8- Hole

MidWestTech | Hitachi ZX670LC-5G Excavator Operational Principle Technical Service... Order the manual at mid-west-tech.com >



TJBA-03-01-021



TJBA-03-01-022

Dr- Returning to Hydraulic Oil Tank
Pi- Flow Rate Control Pressure
Pg- Primary Pilot Pressure (From Pilot Pump)

1- Servo Piston
4- Spring
5- Sleeve
6- Piston
8- Spool
10- Pin
11- Pin
13- Link

MidWestTech | Hitachi ZX670LC-5G Excavator Operational Principle Technical Service... Order the manual at mid-west-tech.com >