
ILLUSTRATED PARTS LIST

KUBOTA

U35

Excavator



Kubota

Order the manual at mid-west-tech.com >

CONTROL PEDAL (SWIVEL/SWING CHANGE 1)

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	RC411-65080	PLATE	1				0.022	0.0484
020	RP421-65190	PIN JOINT	1				0.003	0.0066
030	05525-60500	PIN SNAP	1				0.001	0.0022
040	RC411-65112	ASSY LINK SWING	1				0.23	0.506
050	08511-01615	BUSH	2				0.01	0.022
060	RC411-65172	SHAFT LINK	1	<=20369			0	0
060	RC411-65173	SHAFT LINK	1	>=20370	←		0.66	1.452
070	01123-60816	BOLT	1				0.01	0.022
080	99999-99999	BLANK	0				0	0
090	99999-99999	BLANK	0				0	0
100	99999-99999	BLANK	0				0	0
110	RC411-65530	ASSY LINK SWING	1				0.2	0.44
120	08511-01615	BUSH	2				0.01	0.022
130	04011-60160	WASHER PLAIN	1				0.01	0.022
140	05525-51600	PIN SNAP	1				0.003	0.0066
150	68221-34320	ROD ADJUSTING	1				0.045	0.099
160	52300-75170	BALL LINK	1				0.1	0.22
170	52300-75190	BALL LINK	1				0.115	0.253
180	02116-60100	NUT	1				0.004	0.0088
190	68011-32680	NUT LOCK	1				0.006	0.0132
200	04512-60100	WASHER SPRING	2				0.002	0.0044
210	02118-60100	NUT	2				0.006	0.0132
220	RC611-65920	CABLE	1				0.5	1.1
230	31355-82940	CONNECTOR CABLE	1				0.04	0.088
240	05122-61020	PIN JOINT	1				0.02	0.044
250	04013-60100	WASHER PLAIN	1				0.003	0.0066
260	05525-61000	PIN SNAP	1				0.002	0.0044
270	04013-60100	WASHER PLAIN	2				0.003	0.0066
280	05525-61000	PIN SNAP	2				0.002	0.0044

MidWestTech | Kubota U35 Excavator Parts Manual | Publication U35 Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	RC718-92310	HOSE HYDRAULIC	1				1.37	3.014
020	RC718-92320	HOSE HYDRAULIC	1				1.27	2.794
030	RC411-92370	CLAMP	2				0.07	0.154
035	RC411-92370	CLAMP	2				0.07	0.154
040	RC411-92380	CUSHION HOSE	2				0.06	0.132
045	RC411-92380	CUSHION HOSE	2				0.06	0.132
050	01133-61035	BOLT	4	<=20156			0.027	0.0594
050	01133-61040	BOLT	4	>=20157	≠		0.03	0.066
055	01133-61035	BOLT	4				0.027	0.0594
060	31391-16840	SPACER	4				0.017	0.0374
065	31391-16840	SPACER	4				0.017	0.0374
070	RC418-92350	PIPE	1				1.45	3.19
080	RC418-92360	PIPE	1				1.42	3.124
090	68311-64250	PLUG	2				0.08	0.176
095	04810-00180	O RING	2				0	0
100	01135-61055	BOLT	2				0.21	0.462
110	69738-92300	ASSY CLAMP	2				0.1	0.22
115	01133-61055	BOLT	2				0.04	0.088
120	RC411-92412	HOSE HYDRAULIC	2				0.67	1.474
130	RC418-92430	PIPE	1	<=20341		REPLACE A&B PARTS ALTOGETHER	1.5	3.3
130	RC418-92435	PIPE	1	>=20342	≠	A	1.5	3.3
140	RC418-92440	PIPE	1	<=20341		REPLACE B&C PARTS ALTOGETHER	2.06	4.532
140	RC418-92445	PIPE	1	>=20342	≠	C	2.06	4.532
150	69738-92300	ASSY CLAMP	2				0.1	0.22
160	01133-61055	BOLT	2				0.04	0.088
170	01135-61020	BOLT	4				0.015	0.033
180	68271-63420	ADAPTER	2				0.075	0.165
190	04817-00180	O RING	2				0.003	0.0066
200	RC511-92512	HOSE HYDRAULIC	2	<=20341		REPLACE ABC PARTS ALTOGETHER	1.05	2.31
200	RC718-92560	HOSE HYDRAULIC	2	>=20342	≠	B	1.08	2.376
210	RC418-92970	PIPE HYDRAULIC	2				0.58	1.276
220	68318-92240	CLAMP	4				0.125	0.275
230	01133-61020	BOLT	8				0.02	0.044
240	06312-10040	PLUG	2				0.04	0.088

MidWestTech | Kubota U35 Excavator Parts Manual | Publication U35 Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	RC418-66770	PIN	1				1.98	4.356
020	06611-15010	NIPPLE GREASE	1				0.01	0.022
030	01133-61630	BOLT	1				0.08	0.176
040	68271-42170	WASHER	1				0.12	0.264
050	RC418-66700	ASSY LINK BUCKET	1				10.1	22.22
060	68741-66770	BUSH	2				0.17	0.374
070	68741-66625	BUSH	2				0.23	0.506
080	RC401-66620	COLLAR	1				0.098	0.2156
090	RC411-66780	SEAL DUST	6				0.008	0.0176
100	RC418-66720	LINK BUCKET	1				3.02	6.644
110	RC418-66730	LINK BUCKET	1				3.04	6.688
120	RC418-66750	PIN	1				1.95	4.29
130	06611-15010	NIPPLE GREASE	1				0.01	0.022
140	RC411-66930	SHIM	1			AS REQUIRED 1.0mm	0.025	0.055
140	RC411-66920	SHIM	1			AS REQUIRED 0.5mm	0.012	0.0264
150	01133-61630	BOLT	1				0.08	0.176
160	68271-42170	WASHER	1				0.12	0.264
170	RC418-66760	PIN	2				2.47	5.434
180	06611-15010	NIPPLE GREASE	2				0.01	0.022
190	RC411-66930	SHIM	2			AS REQUIRED 1.0mm	0.025	0.055
190	RC411-66920	SHIM	2			AS REQUIRED 0.5mm	0.012	0.0264
200	68741-66920	SPACER	2				0.01	0.022
210	04015-60120	WASHER PLAIN	2				0.022	0.0484
220	01133-61225	BOLT	2				0.037	0.0814
230	68761-66850	O RING	4				0.01	0.022

MidWestTech | Kubota U35 Excavator Parts Manual | Publication U35 Order the manual at mid-west-tech.com >