UEPB005302

PARTS BOOK

PC340LCD/ NLCD-7K

HYDRAULIC EXCAVATOR

HIGH REACH DEMOLITION MACHINE

MACHINE SERIAL NUMBER

K40575 and up

WARNING

Unsafe use of this machine may cause serious injury or death. Operators and maintenance personnel must read this manual before operating or maintaining this machine. This manual should be kept near the machine for reference and periodically reviewed by all personnel who will come into contact with it.

NOTICE

Komatsu has Operation & Maintenance Manuals written in some other languages. If a foreign language manual is necessary, contact your local distributor for availability.

KOMATSU®

MidWestTech | Komatsu PC340LCD-7K, PC340NLCD-7K Hydraulic Excavator Operation &... Order the manual at mid-west-tech.com >

CONTENTS

PARTS LIST

ELECTRICAL SYSTEM

E0200-01A0 : TILT CAB MAIN HARNESS (HARNESS, CLIP) 6
E0200-02A0 : TILT CAB MAIN HARNESS (CLIP) 8
E0200-03A0 : TILT CAB MAIN HARNESS (CLAMP) 10

MAIN/REVOLVING FRAME AND RELATED PARTS

J1110-01A0 : REVOLVING FRAME (TILT CAB) 14
J1110-02A0 : TILT FRAME (TILT CYLINDER AND PINS 16
J1110-03A0 : TILT FRAME (LUBRICATION PIPING) 18
J1110-04A0 : TILT FRAME (PIPING) 20
J1110-05A0 : PROXIMITY SWITCH 24

OPERATOR'S COMPARTMENT AND CONTROL SYSTEM

K0210-01A0 : OPERATOR'S CAB (FRONT WINDOW) 28
K0210-02A0 : OPERATOR'S CAB (ROOF WINDOW) 32
K0210-03A0 : OPERATOR'S CAB (DOOR LOCK) 34
K0210-04A0 : OPERATOR'S CAB (OPEN LOCK) 36
K0210-05A0 : OPERATOR'S CAB (ACCESSORIES) 38
K0210-06A0 : OPERATOR'S CAB (BLIND BOLT) 40
K0210-07A0 : OPERATOR'S CAB (ROOF WIPER) 42
K0210-08A0 : OPERATOR'S CAB (ROOF WIPER HOSE) 44
K0210-09A0 : OPERATOR'S CAB (CONTROL PANEL) 46
K0220-01A0 : OPG GUARD 48
K0350-01A0 : WINDOW WASHER TANK G. 50
K1110-01A0 : FLOOR (FLOOR FRAME)(TILT CAB) 52

MidWestTech | Komatsu PC340LCD-7K, PC340NLCD-7K Hydraulic Excavator Operatio... Order the manual at mid-west-tech.com >

K1110-02A0 : FLOOR (CONTROL GROUP)(TILT CAB) 54
K1110-03A0 : FLOOR (A/C HOSE)(TILT CAB) 56
K1110-04A0 : FLOOR (HEATER HOSE)(TILT CAB) 58
K1110-05A0 : FLOOR (PPC)(TILT CAB)(1/2) 60
K1110-06A0 : FLOOR (PPC)(TILT CAB)(2/2) 62
K1110-07A0 : SAFETY VALVE LINE 64
K1110-08A0 : TILT CAB HYDRAULICS (A) 66
K1110-09A0 : TILT CAB HYDRAULICS (B) 70
K1110-10A0 : TILT CAB HYDRAULICS (C) 74

GUARD

M1120-01A0 : FRAME (MACHINE CAB) 78
M1210-01A0 : COVER (UPPER)(MACHINE CAB) 80
M1510-01A0 : COUNTER WEIGHT 82
M1810-01A0 : DEMO CAB UNDERCOVERS (L.H.) 84
M1810-02A0 : DEMO CAB UNDERCOVERS (R.H.) 86
M1810-03A0 : DEMO CAB SIDE GUARDS 88
M1810-04A0 : TILT CAB UNDERCOVERS (R.H.) 90
M1810-05A0 : TILT CAB UNDERCOVERS (L.H.) 92
M1810-06A0 : TILT CAB SIDE GUARDS 94
M1810-07A0 : TILT CAB COVERS (CAB) 96

UNDERCARRIAGE

R1000-01A0 : HYDRAULIC TRACK FRAME 100
R1000-02A0 : HYD. TRACK FRAME CONTROL PIPING 102

WORK EQUIPMENT

T1110-01A0 : 1ST, 2ND, 3RD BOOM PINS AND BUSHINGS 106
T1110-02A0 : 1ST BOOM LUBE PIPING 108
T1110-03A0 : 1ST BOOM PIPING 110

MidWestTech | Komatsu PC340LCD-7K, PC340NLCD-7K Hydraulic Excavator Operatio... Order the manual at mid-west-tech.com >

T1110-04A0 : 1ST BOOM PIPING CLAMPS 112
T1110-05A0 : 1ST BOOM QUICK CHANGE UNIT 116
T1110-06A0 : 1ST BOOM WORKLAMP 118
T1110-07A0 : 1ST BOOM ANGLE INDICATOR 120
T1110-08A0 : 2ND BOOM PIPING 122
T1110-09A0 : 3RD BOOM PIPING 124
T1110-10A0 : 1ST, 2ND, 3RD BOOM FASTER PIPING 128
T1110-11A0 : 1ST, 2ND, 3RD BOOM FASTER PIPE CLAMPS 132
T1110-12A0 : MID LINK PINS AND BUSHINGS 137
T1110-13A0 : DIG BOOM PIPING 139
T1120-01A0 : MID LINK CYLINDER DETAIL 143
T1140-01A0 : ARM CYLINDER DETAIL 147
T1210-01A0 : ARM PINS AND BUSHINGS 151
T1210-02A0 : MID LINK AND ARM PIPING 153
T1210-03A0 : MID LINK AND ARM PIPING CLAMPS 157
T1210-04A0 : MID LINK AND ARM CYLINDER S/V PIPING 159
T1210-05A0 : ARM 3.2M (DIG BOOM) 163
T1210-05A0 : ARM 2.5M (DIG BOOM) 165
T1220-01A0 : ATTACHMENT CYLINDER DETAIL 167
T1230-01A0 : LINK PINS AND BUSHINGS 169
X1000-01A0 : TRANSPORT PIN 171
X1000-02A0 : HIGH REACH WORK EQUIPMENT STANDS 173
X1000-03A0 : DIG BOOM STAND 175

MidWestTech | Komatsu PC340LCD-7K, PC340NLCD-7K Hydraulic Excavator Operatio... Order the manual at mid-west-tech.com >

J1110-03A0 : TILT FRAME (LUBRICATION PIPING)

Item	Part No.	Description	Qty	Options
1	207-70-KD290	ADAPTER	6	
2	207-70-KD311	HOSE	2	
3	207-70-KD320	HOSE	2	
4	207-70-KD330	HOSE	1	
5	207-70-KD340	HOSE	1	
6	20Y-54-83760	ADAPTER	6	
7	20Y-54-83780	ELBOW	6	
8	07020-00000	FITTING	6	

MidWestTech | Komatsu PC340LCD-7K, PC340NLCD-7K Hydraulic Excavator Operatio... Order the manual at mid-west-tech.com >

K1110-02A0 : FLOOR (CONTROL GROUP)(TILT CAB)

Item	Part No.	Description	Qty	Options
1	207-62-K4170	HOSE	1	
2	207-62-K4160	HOSE	1	
3	207-62-K4160	HOSE	1	
4	207-62-K4180	HOSE	1	


MidWestTech | Komatsu PC340LCD-7K, PC340NLCD-7K Hydraulic Excavator Operatio... Order the manual at mid-west-tech.com >

M1510-01A0 : COUNTER WEIGHT

Item	Part No.	Description	Qty	Options
	207-46-K2530	WEIGHT	1	
1	207-46-K2520	WEIGHT	1	
2	207-46-74140	SHEET	1	
3	207-46-74160	SHEET	1	
4	207-46-81930	SHEET	1	
5	01370-00508	SCREW	1	
6	207-46-K2510	COVER	1	
7	01010-81250	BOLT	4	
8	01643-31232	WASHER	4	
9	207-46-81720	WEIGHT	1	
10	207-46-81740	BOLT	4	
11	01643-33080	WASHER	4	
12	20Y-46-11270	CAP	2	
13	01010-81220	BOLT	1	
14	01643-31232	WASHER	1	
15	04530-14870	EYE BOLT	2	

MidWestTech | Komatsu PC340LCD-7K, PC340NLCD-7K Hydraulic Excavator Operatio... Order the manual at mid-west-tech.com >

T1140-01A0 : ARM CYLINDER DETAIL



MidWestTech | Komatsu PC340LCD-7K, PC340NLCD-7K Hydraulic Excavator Operatio... Order the manual at mid-west-tech.com >