OPERATOR'S MANUAL

EH160
CRAWLER EXCAVATORS



YM91ZU0004F1-01NA

MidWestTech | New Holland EH160 Crawler Excavator Operator's Manual | Publication YM...

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

CHAPTER 1
GENERAL INFORMATION
To the Owner 1-1
Right, Left, Front, and Rear of the Machine 1-2
Machine Components 1-3
Identification Numbers 1-4

CHAPTER 2
SAFETY, DECALS, AND HAND SIGNALS
Table of Contents 2-1
Safety Rules 2-3
Operator Precautions 2-4
Decals 2-10
Hand Signals 2-27

CHAPTER 3
INSTRUMENTS AND CONTROLS
Table of Contents 3-1
Operator Cab and Operator Seat 3-3
Machine Access Compartments and Doors 3-9
Operator's Compartment Controls and Accessories 3-11
Operating Levers and Controls 3-37

CHAPTER 4
OPERATING INSTRUCTIONS
Table of Contents 4-1
Before Operating the Machine 4-3
Operating the Machine 4-3
Starting & Stopping Machine Engine with Temperature above 0°C (32°F) 4-4
Starting & Stopping Machine Engine with Temperature below 0°C (32°F) 4-5
Starting Machine Engine with Booster Cable 4-6
Machine Warm Up 4-8
Control Decal 4-10
Basic Operation of Hydraulic Controls 4-11
Using Auto Acceleration 4-18
Practices to Improve Efficiency 4-19
Machine Operation in Adverse Weather Conditions 4-21
Recommendation for Longer Undercarriage Life 4-22
Bucket Selection Guide 4-22
Use of Optional Attachment 4-23
Transportation 4-35
Machine Storage 4-42

CHAPTER 5
LUBRICATION, FILTERS, AND FLUIDS
Table of Contents 5-1
Fluids and Filters 5-3
Lubricant Specifications 5-5
Use of Bio-Degradable Oils 5-6

CHAPTER 6
MAINTENANCE AND ADJUSTMENTS
Table of Contents 6-1
General Information 6-5
General Safety 6-5

MidWestTech | New Holland EH160 Crawler Excavator Operator's Manual | Publication YM... Order the manual at mid-west-tech.com >

Inspection & Maintenance Chart 6-10
Pre-start (every 8 hours) Inspection & Maintenance 6-13
50 Hour (weekly) & New Machine Break-in Inspection & Maintenance Procedures 6-23
120 Hour Inspection & Maintenance Procedures 6-36
250 Hour (3-month) Inspection & Maintenance Procedures 6-38
500 Hour (6-month) Inspection & Maintenance Procedures 6-42
Change Oil in Swing Reduction Unit 6-42
1000 Hour (12-month) Inspection & Maintenance Procedures 6-45
2000 Hour Inspection & Maintenance Procedures 6-46
Periodical Inspection Items 6-55
Maintenance for Nibbler/Breaker 6-64
Special Procedures 6-65

CHAPTER 7
ELECTRICAL
Table of Contents 7-1
Electrical Components 7-3

CHAPTER 8
SPECIFICATIONS
Table of Contents 8-1
EC160LC General Specifications 8-3
EH160LC Performance Specifications 8-7
Machine and Components Weights 8-9
Lifting Capacities 8-10
Torque Specifications 8-21

CHAPTER 9
INDEX

MidWestTech | New Holland EH160 Crawler Excavator Operator's Manual | Publication YM... Order the manual at mid-west-tech.com >