PARTS CATALOG

EH160
CRAWLER EXCAVATOR

YM91ZU0003F1-01NA

NEW HOLLAND
CONSTRUCTION

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

02 -01	00	ENGINE MOUNTING
02 -02	00	ENGINE ASSY
02 -03	00	ENGINE CONTROL ASSY
02 -04	00	AIR CLEANER ASSY
02 -05	00	MUFFLER ASSY
02 -06	00	RADIATOR MOUNTING
02 -07	00	RADIATOR MOUNTING
02 -08	00	RADIATOR ASSY
02 -09	00	WATER PUMP SYSTEM
02 -10	00	THERMOSTAT AND HOUSING
02 -11	00	GEAR HOUSING
02 -12	00	MANIFOLD - INTAKE
02 -13	00	MANIFOLD - EXHAUST
02 -14	00	OIL PUMP
02 -15	00	POWER STEERING OIL PUMP - MOUNTING
02 -16	00	OIL FILTER
02 -17	00	OIL COOLER
02 -18	00	OIL LINES
02 -19	00	OIL PAN AND GAUGE
02 -20	00	SERVICE CYLINDER HEAD
02 -21	00	CYLINDER HEAD
02 -22	00	SERVICE CYLINDER BLOCK
02 -23	00	CYLINDER BLOCK
02 -24	00	SERVICE CRANKSHAFT ASSY
02 -25	00	PISTON
02 -26	00	CRANKSHAFT AND PISTON
02 -27	00	CAMSHAFT
02 -28	00	FLYWHEEL AND HOUSING
02 -29	00	CYLINDER HEAD AND COVER
02 -30	00	INTERCOOLER
02 -31	00	TURBOCHARGER ASSY
02 -32	00	TURBOCHARGER
02 -33	00	ATTACHING PARTS
02 -34	00	GASKET KIT
02 -35	00	ELEMENT KIT
02 -36	00	ENGINE FILTERS
03 -01	00	FUEL TANK
03 -02	00	FUEL LINES
03 -03	00	WATER SEPARATOR ASSY
03 -04	00	FUEL FILTER
03 -05	00	FUEL INJECTION PUMP ASSY
03 -06	00	INJECTION PUMP
03 -07	00	GOVERNOR
03 -08	00	GOVERNOR
03 -09	00	FUEL INJECTION PUMP
03 -10	00	FUEL INJECTION NOZZLE
03 -11	00	FUEL INJECTION LINES
03 -12	00	FUEL, RETURN HOSE
04 -01	00	STARTER MOUNTING
04 -02	00	STARTER MOTOR
04 -03	00	ALTERNATOR MOUNTING

MidWestTech | New Holland EH160 Crawler Excavator Parts Catalog | Publication YM91Z... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

04 -04	00	ALTERNATOR
04 -05	00	RELAY BOX ASSY
04 -06	00	HARNESS ASSY, UPPERSTRUCTURE
04 -07	00	HARNESS ASSY, UPPERSTRUCTURE
04 -08	00	HARNESS ASSY, UPPERSTRUCTURE
04 -09	00	HARNESS ASSY (CAB)
04 -10	00	HARNESS ASSY (ENGINE)
04 -11	00	HARNESS ASSY (PLATE, FLOOR)
04 -12	00	HARNESS ASSY (PLATE, FLOOR)
04 -13	00	HARNESS ASSY (PLATE, FLOOR)
04 -14	00	HARNESS ASSY AND RELAY
04 -15	00	HARNESS ASSY AND RELAY
04 -16	00	HARNESS ASSY (BOOM)
04 -17	00	HORN MOUNTING
04 -18	00	BATTERY MOUNTING
04 -19	00	LAMP MOUNTING
04 -20	00	WARNING LAMP ASSY
04 -21	00	LAMP MOUNTING - BOOM
04 -22	00	LAMP - BOOM
04 -23	00	ALARM ASSY
04 -24	00	CONNECTORS
05 -01	00	UNDERCARRIAGE
05 -02	00	UNDERCARRIAGE BLOCK
05 -03	00	UNDERCARRIAGE - BLOCK (COVER ASSY)
05 -04	00	COVER ASSY , UNDER
05 -05	00	UNDERCARRIAGE (HIGH AND WIDE)
05 -06	00	UNDERCARRIAGE BLOCK (HIGH & WIDE)
05 -07	00	UNDERCARRIAGE - ROCK GUARD (HIGH & WIDE)
05 -08	00	ROCK GUARD (HIGH & WIDE)
05 -09	00	TRACK - SHOE
05 -10	00	TRACK - IDLER
05 -11	00	TRACK - IDLER ASSY
05 -12	00	TRACK - ADJUSTER
05 -13	00	TRACK - ROLLER ASSY
05 -14	00	TRACK - ROLLER, UPPER
05 -15	00	TRACK - ROLLER, UPPER (HIGH AND WIDE)
06 -01	00	POWER TAKE OFF ASSY
06 -02	00	MOTOR - TRACK DRIVE ASSY
06 -03	00	MOTOR - TRACK DRIVE
06 -04	00	MOTOR - TRACK DRIVE (GEAR ASSY, REDUCTION)
08 -01	00	HYDRAULIC TANK ASSY
08 -02	00	HYDRAULIC LINES - HYDRAULIC PUMP
08 -03	00	HYDRAULIC LINES - HYDRAULIC PUMP
08 -04	00	HYDRAULIC LINES - HYDRAULIC PUMP - ROTATION
08 -05	00	HYDRAULIC LINES - HYDRAULIC PUMP - ROTATION
08 -06	00	HYDRAULIC LINES, MAIN
08 -07	00	HYDRAULIC LINES, MAIN
08 -08	00	HYDRAULIC LINES - NIBBLER AND BREAKER
08 -09	00	HYDRAULIC LINES - NIBBLER AND BREAKER
08 -10	00	HYDRAULIC LINES, RETURN
08 -11	00	HYDRAULIC LINES, RETURN

MidWestTech | New Holland EH160 Crawler Excavator Parts Catalog | Publication YM91Z... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

08 -12	00	HYDRAULICS - PILOT CONTROL LINES, REMOTE CONTROL
08 -13	00	HYDRAULICS - PILOT CONTROL LINES, REMOTE CONTROL
08 -14	00	HYDRAULICS - PILOT CONTROL LINES, REMOTE CONTROL
08 -15	00	HYDRAULICS - PILOT CONTROL LINES, REMOTE CONTROL, NIBBLER AND BREAKER
08 -16	00	HYDRAULICS - PILOT CONTROL LINES, REMOTE CONTROL, NIBBLER AND BREAKER
08 -17	00	HYDRAULICS - PILOT CONTROL LINES, REMOTE CONTROL, NIBBLER AND BREAKER
08 -18	00	HYDRAULICS - PILOT CONTROL LINES, REMOTE CONTROL, BREAKER
08 -19	00	HYDRAULICS - PILOT CONTROL LINES, REMOTE CONTROL, BREAKER
08 -20	00	HYDRAULICS - PILOT CONTROL LINES, REMOTE CONTROL, BREAKER
08 -21	00	HYDRAULICS - PILOT CONTROL LINES, REMOTE CONTROL, BOOM AND ARM
08 -22	00	HYDRAULICS - PILOT CONTROL LINES, REMOTE CONTROL, BOOM AND ARM
08 -23	00	HYDRAULICS - PILOT CONTROL LINES, REMOTE CONTROL, BOOM AND ARM
08 -24	00	HYDRAULICS - PILOT CONTROL LINES, REMOTE CONTROL, BOOM AND ARM, NIBBLER AND BREAKER
08 -25	00	HYDRAULICS - PILOT CONTROL LINES, REMOTE CONTROL, BOOM AND ARM, NIBBLER AND BREAKER
08 -26	00	HYDRAULICS - PILOT CONTROL LINES, REMOTE CONTROL, BOOM AND ARM, NIBBLER AND BREAKER
08 -27	00	HYDRAULICS - PILOT CONTROL LINES, REMOTE CONTROL, BOOM AND ARM, BREAKER
08 -28	00	HYDRAULICS - PILOT CONTROL LINES, REMOTE CONTROL, BOOM AND ARM, BREAKER
08 -29	00	HYDRAULICS - PILOT CONTROL LINES, REMOTE CONTROL, BOOM AND ARM, BREAKER
08 -30	00	HYDRAULICS - PILOT CONTROL LINES, REMOTE CONTROL (HAND CONTROL - 1 WAY)
08 -31	00	HYDRAULICS - PILOT CONTROL LINES, REMOTE CONTROL (HAND CONTROL - 2 WAY)
08 -32	00	HYDRAULICS - PILOT CONTROL LINES, TRAVEL
08 -33	00	HYDRAULICS - PILOT CONTROL LINES, TRAVEL
08 -34	00	HYDRAULICS - PILOT CONTROL LINES, TRAVEL
08 -35	00	HYDRAULICS - PILOT CONTROL LINES, REMOTE CONTROL, NIBBLER & BREAKER
08 -36	00	HYDRAULICS - PILOT CONTROL LINES, REMOTE CONTROL, MULTI
08 -37	00	HYDRAULICS - REMOTE CONTROL, MULTI - VALVE (SWIVEL)
08 -38	00	HYDRAULIC LINES - VALVE (ROTATION)
08 -39	00	HYDRAULIC LINES - VALVE (ROTATION)
08 -40	00	HYDRAULIC LINES - TRAVEL CONTROL, SINGLE PEDAL
08 -41	00	HYDRAULIC LINES - TRAVEL CONTROL, SINGLE PEDAL
08 -42	00	HYDRAULIC LINES - LOWER
08 -43	00	HYDRAULIC LINES - LOWER
08 -44	00	HYDRAULIC LINES - LOWER, HIGH AND WIDE
08 -45	00	HYDRAULIC LINES - LOWER, HIGH AND WIDE
08 -46	00	HYDRAULIC LINES - BOOM 5.65 M (18 FT. 6 IN.)
08 -47	00	HYDRAULIC LINES - BOOM, NIBBLER AND BREAKER 5.65 M (18 FT. 6 IN.)
08 -48	00	HYDRAULIC LINES - BOOM, NIBBLER AND BREAKER 5.65 M (18 FT. 6 IN.)
08 -49	00	HYDRAULIC LINES - BOOM, 50 FT LONG RANGE 8.75 M (28 FT. 9 IN.)
08 -50	00	HYDRAULIC LINES - ARM 2.94 M (19FT. 8 IN.)
08 -51	00	HYDRAULIC LINES - ARM, NIBBLER & BREAKER
08 -52	00	HYDRAULIC LINES - ARM, NIBBLER & BREAKER
08 -53	00	HYDRAULIC LINES - ARM, 50 FT LONG RANGE 6.35 M (20 FT. 11 IN.)
08 -54	00	PUMP ASSY

Order the manual at mid-west-tech.com >

AIR CONDITIONING COMPRESSOR

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		LC91V00002F2			COMPRESSOR
1		LC91V00001F1		1	COMPRESSOR
2		YX20M01029F2		1	PULLEY ASSY. Incl. 3 - 9
3		24100U1176S25		1	NUT
4		24100U1176S27		1	WASHER, LOCK
5		24100U1176S26		1	WASHER, LOCK
6		(24100U1176S18)		1	BOLT
7		YX20M01029S006		1	SHAFT
8		24100U1176S19		1	STOP
9		LC20M01060P1		1	PULLEY

MidWestTech | New Holland EH160 Crawler Excavator Parts Catalog | Publication YM91Z... Order the manual at mid-west-tech.com >

ARM ASSY , 50 FT LONG REACH, 6.35 M (20 FT. 11 IN.)

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
34		{YN12B01614P1}		2	BUSHING
35		{YN12B01615P1}		2	BUSHING
36		YN12B01597P1		2	BUSHING
		YN12B00435F1			ARM
37		{YN12B01722P1}		1	PIN
38		{YN12B01715P1}		1	PIN
39		HS18C16150G2		1	SCREW M16 x 150mm
40		ZN18C16013		2	NUT M16
41		{2420Z1047}		1	CASTLE M56
42		ZP15D08100		1	PIN
43		{2418Z715}		1	WASHER M56
44		B16T0442D53		1	SHIM t0,5 (92 i.d.)
45		B16T0442D40		1	SHIM t0,9 (92 i.d.)
46		B16T0442D78		1	SHIM t0,5 (92 i.d.)
47		B16T0442D77		1	SHIM t0,9 (87 i.d.)
48		B16T0442D62		1	SHIM t1,6 (87 i.d.)
49		{YN02B01414D1}		1	SHIM, t1,6 (92 i.d.)
50		{YN02B01415D1}			SHIM, t2,0 (87 i.d.)

MidWestTech | New Holland EH160 Crawler Excavator Parts Catalog | Publication YM91Z... Order the manual at mid-west-tech.com >

DECALS

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
1		{VAME441208}		1	NAME PLATE, ENG
2				1	NAME PLATE, ENG
3				1	NAME PLATE, ENG
4		VAME057422		1	PLATE ENG OIL CAUTION

MidWestTech | New Holland EH160 Crawler Excavator Parts Catalog | Publication YM91Z... Order the manual at mid-west-tech.com >